

Manual for Sigfox sensors - Common parts

- [What is Sigfox?](#)
- [Troubleshooting for Sigfox Communication](#)
- [Offline configuration for Sigfox Sensors](#)
- [List of Configuration template files of Sigfox-Ready Sensors](#)
- [Common notes in installation of Sigfox-Ready Sensors](#)

What is Sigfox?

Understanding the Sigfox Connectivity Technologies.

Please find [this link](#) for understanding Sigfox Connectivity Technologies.

Troubleshooting for Sigfox Communication

 This is the troubleshooting for Sigfox communication of Sigfox-ready sensors with FW versions listed below:

| No. | Phenomena | Reason | Solutions |
|-----|---|---|---|
| 1 | Node does not send RF to the base station periodically, LED does not blink | <ul style="list-style-type: none">No power supply or battery ran outThe configuration sending cycle is incorrect | <ul style="list-style-type: none">Check that each battery is empty OR not installed correctlyCheck the power supplyCheck the send cycle configuration |
| 2 | Node does not send RF to the base station according to the alarm, LED does not blink | <ul style="list-style-type: none">The alarm threshold values are incorrect and/or disabled alarm functionRunning out of the number of alarms set for the day | <ul style="list-style-type: none">Check alarm threshold values and alarm enableCheck the configuration for the maximum number of alarms per day |
| 3 | Node does not send RF to the base station when activated by the magnetic switch, LED does not blink | <ul style="list-style-type: none">The magnetic switch has malfunctionedOr place the Magnet key in not right position | <ul style="list-style-type: none">Locate the correct position for the magnet keyRead the status of the magnetic switch via Modbus (when powering or attaching the battery) to see if the magnetic switch is working. |
| 4 | Node has blinked LED when sending RF but the base station cannot receive | <ul style="list-style-type: none">Out of the number of RF packages of uplink per day (max 140 packages/day) | <ul style="list-style-type: none">Check on the base station whether the event message exceeds the number of RF packets |
| 5 | Node has sent RF but the LED does not blink | <ul style="list-style-type: none">LED malfunction | <ul style="list-style-type: none">Contact manufacturer |
| 6 | The node does not send RF and the RF module is hot | <ul style="list-style-type: none">Insert the battery in the wrong directionElectronics got problem | <ul style="list-style-type: none">Check battery polarity |
| 7 | RSSI is weak and often loses data | <ul style="list-style-type: none">Distance between Node and Base station is far or there are many obstructionsConnection to Antenna problem | <ul style="list-style-type: none">Check the location of the Sigfox node and distance to the base stationCheck the antenna connector in the PCB |
| 8 | The measurement values from the sensor do not change and keep constant values for a long time | <ul style="list-style-type: none">Sensor got failureSensor cable brokenThe sensor connector is not connected firmly | <ul style="list-style-type: none">Check sensor cable and connectorIf the issue still exists, please contact the manufacturer for a warranty or replace the new sensor |

Offline configuration for Sigfox Sensors

THIS IS OBSOLETE MANUAL

Please access <https://www.iot.daviteq.com/wireless-sensors> for updated manual

Instructions for offline configuration of the Daviteq Sigfox-Ready sensors. Please follow the following steps.

Note: THE SENSOR IS ONLY ACTIVE FOR CONFIGURATION IN THE FIRST 60 SINCE POWER UP BY BATTERY OR PLUGGING THE CONFIGURATION CABLE.

1. Prepare equipment and tools

The following items must be prepared for configuration.

1. A PC using the Windows OS (Win7 or above versions). The PC is installed with the COM port driver of the Modbus configuration cable (if needed). The driver is at link: [Modbus Configuration Cable COM port driver for PC](#) and the instruction to install the driver at link: [How to install the driver](#)
2. A Modbus configuration cable;
3. Tools to open the housing of Sigfox-ready sensors (L hex key or screwdriver)

2. Download and launch Daviteq Modbus configuration software

- Click the link below to download Daviteq Modbus configuration software:

<https://filerun.daviteq.com/wl/?id=yDOjE5d6kqFIGNVVIMdFg19Aad6aw0Hs>


- After downloading the software, unzip the file named: **Daviteq Modbus Configuration Tool.zip** and then copy the extracted folder to the storage drive for long-term use.
- Open the folder, double click on the file **Daviteq Modbus Configuration Tool Version.exe** to launch the software and the software interface as below:

| FC | REG | #REG | FORMAT | PARAMETER | VALUE ON MEMMAP | VALUE TO WRITE | EXCEPTION | DESCRIPTION |
|----|-----|------|--------|-----------|-----------------|----------------|-----------|-------------|
| * | 1 | | | | | | | |

Note: The software only runs on Microsoft Windows OS (win7 and above).

3. Connect the cable and configure the sensor

Step 1: Connect USB plug of Modbus configuration cable to USB socket of the PC



Step 2: On the configuration software, choose the relevant **Port** (the USB port which is the cable plugged in) and set the **BaudRate: 9600, Parity: none**

Step 3: Click the “ **Connect** ” button to connect the software to the sensor. After a successful connection, the **connected status**(green text) will show on the software.

| FILE | | EDIT | | Status Connected | | Tx <input type="radio"/> Rx <input type="radio"/> | | <table border="1"> <tr><td>POLL</td><td>0</td></tr> <tr><td>RECEIVE</td><td>0</td></tr> <tr><td>CRC_OK</td><td>0</td></tr> <tr><td>CRC_ERROR</td><td>0</td></tr> <tr><td>TIME_OUT</td><td>0</td></tr> </table> | | POLL | 0 | RECEIVE | 0 | CRC_OK | 0 | CRC_ERROR | 0 | TIME_OUT | 0 | <div>Welcome</div> <div>2023.05.18 15:27</div> <div>Disconnected</div> <div>2023.05.18 15:27</div> <div>Disconnected</div> <div>2023.05.18 15:27</div> <div>Connected</div> |
|------------|--------------------------|----------|------|-------------------------|-----------|---|----------------|--|-------------|------|---|---------|---|--------|---|-----------|---|----------|---|---|
| POLL | 0 | | | | | | | | | | | | | | | | | | | |
| RECEIVE | 0 | | | | | | | | | | | | | | | | | | | |
| CRC_OK | 0 | | | | | | | | | | | | | | | | | | | |
| CRC_ERROR | 0 | | | | | | | | | | | | | | | | | | | |
| TIME_OUT | 0 | | | | | | | | | | | | | | | | | | | |
| Port | COM3 | BaudRate | 9600 | Parity | NONE | | | | | | | | | | | | | | | |
| DISCONNECT | | | | | | | | | | | | | | | | | | | | |
| | FC | REG | #REG | FORMAT | PARAMETER | VALUE ON MEMMAP | VALUE TO WRITE | EXCEPTION | DESCRIPTION | | | | | | | | | | | |
| * 1 | <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | |

Step 4: Import the configuration file for the sensor to the software: click menu **File/ Import New** and then browse the relevant sensor template file (csv file) and click **Open** to import the template file.


⚠ Each sensor type has its own template file. Refer to the sensor's manual to download the correct file.

⚠ The sensor is only active for configuration for 60 seconds since plugging the configuration cable or the power supply into the sensor.

Step 5: Open the housing of the sensor and quickly plug the connector of the configuration cable into sensor's modbus configuration port. After plugging the connector, the software will read the parameter values automatically.



- Open the housing of the sensor.



- Plug the cable connector into sensor's modbus configuration port.
Note: this port is located at a different location, depends on the sensor type



The sensor is only active for configuration for 60 seconds since plugging the configuration cable or the power supply into the sensor.

Step 6: Read the current value of the parameter with function 3

- At the relevant row of the parameter, check box **3** on column **FC** to read the value of the parameter. The read value is shown on **VALUE ON MEMMAP** column.

FILE EDIT

Port: COM11 BaudRate: 9600 Parity: NONE

DISCONNE

Status: Connected Tx ● Rx ●

34.287,Rx: 00 03 12 31 32 31 36 30 31 32 31 31 36 30 34 00 00 00 00 00

34.289,Tx: 00 03 01 2F 00 01 B5 EE

34.406,Rx: 00 03 02 00 01 44 44

34.409,Tx: 00 03 01 3D 00 01 15 EB

| POLL | 45 |
|-----------|----|
| RECEIVE | 44 |
| CRC_OK | 44 |
| CRC_ERROR | 0 |
| TIME_OUT | 0 |

Welcome
2023.05.18 15:34
Disconnected
2023.05.18 15:34
Disconnected
2023.05.18 15:34
Connected

| | FC | REG | #REG | FORMAT | PARAMETER | VALUE ON MEMMAP | VALUE TO WRITE | EXCEPTION |
|----|-------------------------------------|-----|------|----------|---------------------------------|---|----------------|-----------|
| 1 | <input type="checkbox"/> | | | | WSLRW-AG-6 ENGINEERING TEMPLATE | | | |
| 2 | <input checked="" type="checkbox"/> | 3 | 0 | 5 string | FW_CODE | STIL | | |
| 3 | <input checked="" type="checkbox"/> | 3 | 5 | 4 string | FW_VERSION | 6F0228 | | |
| 4 | <input checked="" type="checkbox"/> | 3 | 9 | 2 string | HW_VERSION | 2H | | |
| 5 | <input checked="" type="checkbox"/> | 3 | 11 | 4 string | lorawan protocol version | 01 00 03 | | |
| 6 | <input checked="" type="checkbox"/> | 3 | 27 | 4 hex | deviceEUI | 34 31 34 36 52 31 81 15 | | |
| 7 | <input checked="" type="checkbox"/> | 3 | 31 | 4 hex | lora appEUI | 01 02 03 04 05 06 07 08 | | |
| 8 | <input checked="" type="checkbox"/> | 3 | 35 | 8 hex | lora appKey | 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10 | | |
| 9 | <input checked="" type="checkbox"/> | 3 | 63 | 2 string | join mode | OTAA | | |
| 10 | <input checked="" type="checkbox"/> | 3 | 65 | 4 string | network mode | PUBLIC | | |
| 11 | <input checked="" type="checkbox"/> | 3 | 69 | 3 string | region code | EU868 | | |
| 12 | <input checked="" type="checkbox"/> | 3 | 72 | 4 string | data rate | DR5:5470 | | |



The sensor is only active for configuration for 60 seconds since plugging the configuration cable or the power supply into the sensor. After 60 seconds, the TIME_OUT text will show on EXCEPTION column of the software.

Step 7: Write the new setting to the parameter with function 16

- Double click on the column **VALUE TO WRITE** of the parameter and input the new setting of the parameter
- Uncheck the tick on the **FC** column of the parameter, click on the arrow, select **16** and then check on the **FC** column to write a new setting to the parameter. The **WRITE_OK** text will show on **EXCEPTION** column if the software successfully writes the setting.

FILE EDIT

Port
COM11

BaudRate
9600

Parity
NONE

DISCONNE

Status Connected

Tx ● Rx ●

43.299,Tx: 00 03 01 40 00 01 85 F3
43.379,Rx: 00 03 02 00 00 85 84
43.394,Tx: 00 03 01 41 00 01 D4 33
43.459,Rx: 00 03 02 00 00 85 84
43.462,Tx: 00 03 01 56 00 02 24 36

POLL 732

RECEIVE 729

CRC_OK 729

CRC_ERROR 0

TIME_OUT 2

Disconnected
2023.05.18 15:36

Connected
2023.05.18 15:36

Disconnected
2023.05.18 15:44

Connected

| | FC | REG | #REG | FORMAT | PARAMETER | VALUE ON MEMMAP | VALUE TO WRITE | EXCEPTION |
|----|-------------------------------------|-----|------|----------|--|-----------------|----------------|-----------|
| 1 | <input type="checkbox"/> | | | | WSLRW-AG-6 ENGINEERING TEMPLATE | | | |
| 2 | <input checked="" type="checkbox"/> | 3 | 0 | 5 string | FW_CODE | STIL | | |
| 3 | <input checked="" type="checkbox"/> | 3 | 5 | 4 string | FW_VERSION | 6F0228 | | |
| 4 | <input checked="" type="checkbox"/> | 3 | 9 | 2 string | HW_VERSION | 2H | | |
| 5 | <input checked="" type="checkbox"/> | 3 | 72 | 4 string | data rate | DR5:5470 | | |
| 6 | <input checked="" type="checkbox"/> | 16 | 317 | 1 uint | region | 5 | 5 | WRITE_OK |
| 7 | <input checked="" type="checkbox"/> | 3 | 318 | 1 uint | data rate | 5 | | |
| 8 | <input checked="" type="checkbox"/> | 3 | 319 | 1 uint | tx power | 14 | | |
| 9 | <input checked="" type="checkbox"/> | 3 | 320 | 1 uint | adaptative data rate | 0 | | |
| 10 | <input checked="" type="checkbox"/> | 3 | 321 | 1 uint | frequency channels for EU868 IN865 RU864 KR920 AS923 | 0 | | |

- Repeat step 6 to read the setting of the parameter for checking.



The sensor is only active for configuration for 60 seconds since plugging the configuration cable or the power supply into the sensor. After 60 seconds, the TIME_OUT text will show on EXCEPTION column of the software.



For some critical parameters of the sensor, the password in "password for setting" must be written before writing the new settings to these parameters.



Only read/write registers are allowed to write.

4. Troubleshooting

| No. | Phenomena | Reason | Solutions |
|-----|---|--|---|
| 1 | The status on the software always shows Disconnected although the configuration cable is connected to the PC | <ul style="list-style-type: none"> The selected COM port is incorrect. The cable is defective | <ul style="list-style-type: none"> Select the correct COM port to which the configuration cable connects to PC Check the cable |
| 2 | The software reads no value after importing the right template and connecting the right cable. | <ul style="list-style-type: none"> The cable is defective or lost connection The USB port is defective There is no power supply to the sensor via configuration cable The sensor or sensor port is defective | <ul style="list-style-type: none"> Check or replace the new configuration cable Check USB port Check the power line of the cable Check the sensor and sensor port |
| 3 | No COM port appears in the Port list | <ul style="list-style-type: none"> No configuration cable is plugged into the PC The cable driver is not installed on the PC | <ul style="list-style-type: none"> Plug the cable to the PC Install the driver for the PC |
| 4 | The parameter table on the software is empty | <ul style="list-style-type: none"> The template file has not been imported | <ul style="list-style-type: none"> Go to File/Import New to import the template file |

| | | | |
|---|--|---|---|
| 5 | The parameter table on the software does NOT match the memory map table of the sensor. | <ul style="list-style-type: none"> The wrong template file was imported. | <ul style="list-style-type: none"> Go to the correct manual page of the product and download the right template file, then import the template file into the software. |
|---|--|---|---|

5. List of Configuration Template Files for various Sigfox-Ready Sensors

Please find [this link](#) for the template file of each Sigfox-Ready sensor.

END.

List of Configuration template files of Sigfox-Ready Sensors

THIS IS OBSOLETE MANUAL

Please access <https://www.iot.daviteq.com/wireless-sensors> for updated manual

Each Sigfox-Ready Sensor has a template file for Offline configuration. Please find below the list.

| SKU# | Product Description | FW Ver. | Link to download Configuration Template File | Remarks |
|---------------|--|---------|---|---------|
| WSSFC-AC | Sigfox-Ready AC Current Sensor | 1.0 | <i>Template file for WSSFC-AC-FW 1.0- HW 1.0</i> | |
| WSSFC-AC | Sigfox-Ready AC Current Sensor | 3.0 | <i>Template file for WSSFC-AC-FW 3.0</i> | |
| WSSFC-AG | Sigfox-Ready Accelerometer-Gyro Sensor | 1.0 | <i>Template file for WSSFC-AG-FW 1.0- HW 1.0</i> | |
| WSSFC-ATH | Sigfox-Ready integrated ambient humidity and temperature sensor | 1.0 | <i>Template file for WSSFC-ATH-FW 1.0- HW 1.0</i> | |
| WSSFC-CAP10 | Sigfox-Ready high precision capacitance fuel level sensor | 1.0 | <i>Template file for WSSFC-CAP10-FW 1.0 HW 1.0</i> | |
| WSSFC-CO2 | Sigfox-Ready Industrial CARBON DIOXIDE GAS SENSOR, NDIR Type | 1.0 | <i>Template file for WSSFC-CO2-FW 1.0- HW 1.0</i> | |
| WSSFC-LPC | Sigfox-Ready People counter, Lidar technology | 1.0 | <i>Template file for WSSFC-LPC-FW 1.0- HW 1.1</i> | |
| WSSFC-LPC | Sigfox-Ready People counter, Lidar technology | 2.0 | <i>Template file for WSSFC-LPC-FW 2.0- HW 2.0</i> | |
| WSSFC-G4F-NH3 | Sigfox-Ready Gas Sensor, 4-Seri, Ceiling mount type, NH3 | 6.0 | <i>Template file for WSSFC-NH3-FW 6.0-HW 2.0</i> | |
| WSSFC-PPS | Sigfox-Ready Process Pressure Sensor | 1.0 | <i>Template file for WSSFC-PPS-FW 1.0- HW 1</i> | |
| WSSFC-ULC | Sigfox-Ready Ultrasonic level sensor for liquid or flat surface | 1.2 | <i>Template file for WSSFC-ULC-FW 1.2- HW 1.1</i> | |
| WSSFC-V1A | Sigfox-Ready Single Axis Vibration Sensor, 10 KHz Piezo technology | 1.0 | <i>Template file for WSSFC-V1A-FW 1.0- HW 1.1</i> | |
| WSSFCEX-PPS | Sigfox-Ready Process Pressure Sensor with Exd approval | 1.01 | <i>Template file for WSSFCEX-PPS-FW 1.01-HW 1.0</i> | |

| | | | | |
|-------------|---|---|---|--|
| WSSFCEX-GHC | Sigfox-Ready Flammable Gas Sensor with Exd approval | 2 | <i>Template file for WSSFCEX-GHC-FW 2-HW 1</i> | |
| WSSFC-ULA | Sigfox-Ready Ultrasonic level for solid waste | 2 | <i>Template file for WSSFC-ULA-FW 2-HW 2</i> | |

END.

Common notes in installation of Sigfox-Ready Sensors

The common instructions for all kinds of Daviteq Sigfox-Ready Sensor. Please see below.

1. HOW DO YOU GET A STRONG RF SIGNAL?

To maximize the transmission distance, the ideal condition is Line-of-sight (LOS) between the Sigfox-Ready sensor and the Sigfox Base station. In real life, there may be no LOS condition. However, the Sigfox-Ready sensor still communicates with the Base station, but the distance will be reduced significantly.

DO NOT install the wireless sensor or its antenna inside a completed **metallic** box or housing because the RF signal can not pass through the metallic wall. The housing is made from Non-metallic materials like plastic, glass, wood, leather, concrete, and cement...is acceptable.

2. INSTALL BATTERIES FOR SIGFOX-READY SENSOR

2.1 INSTALL BATTERIES FOR SIGFOX-READY SENSOR WITH BLUE BOX HOUSING

RECOMMENDED BATTERIES FOR SIGFOX SENSOR

E91 AA Alkaline battery



-18 .. + 60 oC working temperature

10-year shelf life

3000 mAH Capacity

Price: 1X

L91 AA Lithium battery



-40 .. + 60 oC working temperature

20-year shelf life

3500 mAH Capacity

Price: 3.5X

WSSFC-ULC-H7.PNG

Steps for battery installation:

Step 1: Using L hex key to unscrew M4 screws at the side of the housing and carefully pull out the top plastic housing in the vertical direction



Step 2: Insert 02 x AA 1.5VDC battery, please take note the poles of the battery

ATTENTION:



REVERSED POLARITY OF BATTERIES IN 10 SECONDS CAN DAMAGE THE SENSOR CIRCUIT!!!



Step 3: Insert the top plastic housing and locking by L hex key

ATTENTION:



When reinstalling the cover, pay attention to put the PCB edge into the middle slot of the box inside as shown below)



2.2 INSTALL BATTERIES FOR SIGFOX-READY SENSOR WITH WHITE BOX HOUSING, 6 X AA BATTERIES (SENSOR -LPC)

RECOMMENDED BATTERIES

E91 AA Alkaline battery



-18 .. + 60 oC working temperature
10-year shelf life
3000 mAH Capacity
Price: 1X

L91 AA Lithium battery



-40 .. + 60 oC working temperature
20-year shelf life
3500 mAH Capacity
Price: 3.5X

WSSFC-LPC-H5.PNG


Steps for battery installation:

Step 1: Use flat head screws to push into 2 reed joints



Step 2: Open the housing, then insert 06 x AA 1.5VDC battery, please take note of the poles of the battery

⚠ ATTENTION: REVERSED POLARITY OF BATTERIES IN 10 SECONDS CAN DAMAGE THE SENSOR CIRCUIT!!!



Step 3: Insert the top plastic housing (Please note the 2 reed joints)



2.3 INSTALL BATTERIES FOR SIGFOX-READY SENSOR WITH BLACK BOX HOUSING, 2 X AA BATTERIES (SENSOR -ULA)

RECOMMENDED BATTERIES FOR SIGFOX SENSOR

E91 AA Alkaline battery



-18 .. + 60 oC working temperature

10-year shelf life

3000 mAh Capacity

Price: 1X

L91 AA Lithium battery



-40 .. + 60 oC working temperature

20-year shelf life

3500 mAh Capacity

Price: 3.5X

WSSFC-ULC-H7.PNG

Steps for battery installation:

Step 1: Use a screwdriver to open the 4 screws on the underside of the housing



Step 2: Open the housing, then insert 02 x AA 1.5VDC battery

⚠ ATTENTION: REVERSED POLARITY OF BATTERIES IN 10 SECONDS CAN DAMAGE THE SENSOR CIRCUIT!!!



Step 3: Insert the plastic housing and locking the 4 screws by screwdriver



2.4 INSTALL BATTERIES FOR SIGFOX-READY SENSOR WITH EXD-

APPROVED HOUSING WSSFCEX-...

Depends on the design of each device. Each device may need 1 pc of Type C or Type D battery. Please check the specification of that device. We recommend the below batteries to be used with our devices.



Steps for battery installation:

DANGER:

DO NOT REPLACE BATTERY AT HAZARDOUS LOCATION!



DO NOT OPEN THE COVER AT HAZARDOUS LOCATION!

ONLY OPEN COVER AND REPLACE BATTERY IN SAFE AREA!

Step 1: Turn the front cover of the sensor counter-clockwise;



Step 2: Carefully take out the front cover of the sensor

Step 3: Insert the battery, please take note the polarity of battery

ATTENTION:



REVERSED POLARITY OF BATTERIES IN 10 SECONDS CAN DAMAGE THE SENSOR CIRCUIT!!!



Step 4: Turn the front cover of the sensor clockwise to close fully.



NOTES:



Using 2mm hex key to lock the cover to prevent the unattended opening.




3. MOUNTING FOR SIGFOX-READY SENSOR


3.1 MOUNTING FOR SIGFOX-READY SENSOR WITH BLUE BOX HOUSING

The following are the steps for the Sigfox-ready sensor with a Blue box housing design.

Step 1: Install the bracket on the sensor



Step 2: Determine the mounting position and secure the sensor with the included screws





Step 3:Grounding the sensor



3.2 MOUNTING FOR SIGFOX-READY SENSOR WITH WHITE BOX HOUSING

3.3 MOUNTING FOR SIGFOX-READY SENSOR WITH EXD-APPROVED HOUSING




4. ADDING A SIGFOX-READY SENSOR TO SIGFOX BACK-END SYSTEM

This instruction is applied to all kinds of Sigfox-Ready sensors produced by Daviteq.


Step 1: Log in to the sigfox backend website

A screenshot of a web browser showing the Sigfox backend login page. The address bar displays "backend.sigfox.com/auth/login". The page features the Sigfox logo (a purple and blue stylized 'S') and the text "sigfox". Below the logo, there is a login form with two input fields: "Email address" (with an envelope icon) and "Password" (with a lock icon). Below these fields is a checkbox labeled "Remember me for one week". At the bottom right of the form is a "Sign in" button.

Step 2: Click on Device



Step 3: Click New → Select a group



Step 4: Fill in the required information

Device - New

Device information

Identifier (hex)

Name

PAC

End product certificate

Where can I find the end product certificate?

Type Available Tokens: 0

Lat (-90° to +90°)

Lng (-180° to +180°)

Map [Locate on map](#)


Subscription automatic renewal ☒

Activable ☒



Note: Some of our products may not have end product certification in time, to add the product to Backend Sigfox please follow the steps below.

Click on the text as shown below



DEVICE DEVICE TYPE USER GROUP ▼

ⓘ ? ↗

Device - New

Device information

Identifier (hexl) 0000

Name

PAC

End product certificate ⓘ

Where can I find the end product certificate?

Type ST_Micro_SEmaker_DevKit_1 Available Tokens: 0

Lat (-90° to +90°) 0.0

Lng (-180° to +180°) 0.0

Map Locate on map

Subscription automatic renewal ☒

Activable ☒ ⓘ


Ok Cancel

Copyright © Sigfox - 9.11.1-5cd92a9-20201207.155212 - 302 - Terms and conditions / Cookie policy.

Check the box as shown below to register as a prototype

Device - New

Device information

Identifier (hex) Name PAC End product certificate 

Where can I find the end product certificate?

The device vendor should provide the end product certificate number. If not, please use the search bar below:

Otherwise you can contact your [Sigfox distributor service desk](#)

If the device has not obtained an end product certificate yet, then you can register as a prototype.

☒ Register as a prototype (remaining prototypes which can be registered in your group: 1000)Type Available Tokens: 0Lat (-90° to +90°) Lng (-180° to +180°) Map [Locate on map](#)Subscription automatic renewal ☒Activable ☒ 