


# Troubleshooting for Sigfox Communication

 This is the troubleshooting for Sigfox communication of Sigfox-ready sensors with FW versions listed below:

No.	Phenomena	Reason	Solutions
1	Node does not send RF to the base station periodically, LED does not blink	<ul style="list-style-type: none"><li>No power supply or battery ran out</li><li>The configuration sending cycle is incorrect</li></ul>	<ul style="list-style-type: none"><li>Check that each battery is empty OR not installed correctly</li><li>Check the power supply</li><li>Check the send cycle configuration</li></ul>
2	Node does not send RF to the base station according to the alarm, LED does not blink	<ul style="list-style-type: none"><li>The alarm threshold values are incorrect and/or disabled alarm function</li><li>Running out of the number of alarms set for the day</li></ul>	<ul style="list-style-type: none"><li>Check alarm threshold values and alarm enable</li><li>Check the configuration for the maximum number of alarms per day</li></ul>
3	Node does not send RF to the base station when activated by the magnetic switch, LED does not blink	<ul style="list-style-type: none"><li>The magnetic switch has malfunctioned</li><li>Or place the Magnet key in not right position</li></ul>	<ul style="list-style-type: none"><li>Locate the correct position for the magnet key</li><li>Read the status of the magnetic switch via Modbus (when powering or attaching the battery) to see if the magnetic switch is working.</li></ul>
4	Node has blinked LED when sending RF but the base station cannot receive	<ul style="list-style-type: none"><li>Out of the number of RF packages of uplink per day (max 140 packages/day)</li></ul>	<ul style="list-style-type: none"><li>Check on the base station whether the event message exceeds the number of RF packets</li></ul>
5	Node has sent RF but the LED does not blink	<ul style="list-style-type: none"><li>LED malfunction</li></ul>	<ul style="list-style-type: none"><li>Contact manufacturer</li></ul>
6	The node does not send RF and the RF module is hot	<ul style="list-style-type: none"><li>Insert the battery in the wrong direction</li><li>Electronics got problem</li></ul>	<ul style="list-style-type: none"><li>Check battery polarity</li></ul>
7	RSSI is weak and often loses data	<ul style="list-style-type: none"><li>Distance between Node and Base station is far or there are many obstructions</li><li>Connection to Antenna problem</li></ul>	<ul style="list-style-type: none"><li>Check the location of the Sigfox node and distance to the base station</li><li>Check the antenna connector in the PCB</li></ul>
8	The measurement values from the sensor do not change and keep constant values for a long time	<ul style="list-style-type: none"><li>Sensor got failure</li><li>Sensor cable broken</li><li>The sensor connector is not connected firmly</li></ul>	<ul style="list-style-type: none"><li>Check sensor cable and connector</li><li>If the issue still exists, please contact the manufacturer for a warranty or replace the new sensor</li></ul>

 Revision #4

★ Created Thu, Jun 23, 2022 7:24 PM by [Lộc Vĩnh Nguyễn](#)

✎ Updated Wed, Jun 29, 2022 11:42 PM by [Lộc Vĩnh Nguyễn](#)