

USER GUIDE FOR SIGFOX LIDAR PEOPLE COUNTER WSSFC-LPC

THIS IS OBSOLETE MANUAL


Please access <https://www.iot.daviteq.com/wireless-sensors> for updated manual

WSSFC-LPC-MN-EN-01	AUG-2021
--------------------	----------

This document is applied for the following products

SKU	WSSFC-LPC	HW Ver.	1.1	FW Ver.	1.0
Item Code	WSSFC-LPC-9-01	SIGFOX LIDAR PEOPLE COUNTER, INTERNAL ANTENNA, TYPE AA BATTERY 1.5VDC, IP5X, RC2-RC3-RC4-RC5 ZONES			
	WSSFC-LPC-8-01	SIGFOX LIDAR PEOPLE COUNTER, INTERNAL ANTENNA, TYPE AA BATTERY 1.5VDC, IP5X, RC1-RC6-RC7 ZONES			

0. Configuration Check List



STEP 1: Select RC	
-------------------	--

1. Select RC zone	RC zones selection 1, 2, 4,... is RCZ1, RCZ2, RCZ4,... (refer to section 6)
STEP 2: Check ID and PAC	
Use Modbus Configuration Cable to read the ID and PAC values	Refer to register address 8 and 10 (DEC)
STEP 3: Configure the sensor's operating parameters	
Configure parameters like cycle send data, alarm, a, b,...	Refer to the configuration section 5 and section 6
STEP 4: Add device to Backend Sigfox	
refer to section 5.2 for details	
STEP 5: Installation	
refer to section 7 for details	

1. Functions Change Log

HW Ver.	FW Ver.	Release Date	Functions Change
1.1	1.0	DEC-2020	

2. Introduction

WSSFC-LPC is a Sigfox sensor with built-in advanced Lidar sensor to detect and ranging people. It can count the people walk thru with accuracy higher than 90%. The sensor is not affected by temperature, humidity, RF noise and less affected by ambient light... With Ultra-low power design and smart firmware allow the complete Wireless and Sensor package run on AA battery 1.5V in many years. Moreover, it can be powered by external power supply at the same time. It can support all regions of Sigfox network in over the World, RC1, RC2, RC3, RC4, RC5, RC6, RC7.

Typical Applications: People counter for public toilet, People counter for Store, shop...

SIGFOX LIDAR PEOPLE COUNTER
WSSFC-LPC



WSSFC-LPC-H1.PNG


3. Specification

SENSOR SPECIFICATION	
Sensor technology	Lidar
Detection range	max 4m
Detection cone	27 degree
Working temperature	-40 .. + 60 oC
Working humidity	0 .. 100% RH, non-condensing
SIGFOX SPECIFICATION	
Sigfox zones	select RC2-RC3-RC4-RC5 or RC1-RC6-RC7
Functions	Sending data in interval or when alarms occur
Antenna	Internal Antenna 2 dbi
Configuration	via offline USB cable (PC software is supplied at free)
Battery	Battery AA Type 1.5VDC and 7..48VDC (AC adapter not included)
RF Module complies to	CE, FCC, ARIB
Working temperature	-40°C..+60oC (using Energizer Lithium Ultimate AA battery)

Dimensions	H120xW80xD45
Net-weight	<150 grams
Housing	Self-extinguisher ABS, Dust and vapor protection
Mounting	Ceiling mount

4. Dimensions

DIMENSION DRAWING OF WIRELESS SENSOR (Unit: mm)



5. Operation Principle

i Upon power on, the Sigfox node has **60 seconds** to wait for **off-line** configuration (via **cable** with **ModbusRTU** protocol)

After 1 minute 30 seconds later the device will send the first data packet and at the same time wait for the downlink packet from the Base Station.

Then during the operation, there are 03 cases of sending data to base station:

1. When the sensor sampling time interval is reached, the Sigfox node will read the data from Input or sensor and performing the calculation. After that it will check calculated value with alarm thresholds. If the calculated was out off the threshold values (Lo or Hi), called alarm, and the number of times of alarm did not pass the limit of number of alarms, then it will send data to Base station immediately;

NOTE:



Once sending the data to base station by this alarm event, the timer of sending time interval will be reset;


2. When the sending time interval is reached, it will send data to Base station immediately, regardless of value;

3. By using the magnet key, the Sigfox node can be triggered to send data to base station immediately. There will be a beep sound from the buzzer meaning the data has been sent. (Buzzer will be updated in the latest version)



NOTE:

- Once sending the data to base station by the magnet key, the timer of sending time interval will be reset;
- The shortest time interval between the two manual triggers is **15s**. if shorter than **15s**, there will be no data sending.



5.1 RC technical details

The RF transmit power will be automatically set as the max value as allowed by the Zone.

Sigfox Radio Configuration (RC) defines the radio parameters in which the device shall operate: Sigfox operating frequencies, output power, spectrum access mechanism, throughput, coexistence with other radio technologies, etc.

Each radio configuration includes 4 uplink classes: 0u, 1u, 2u, and 3u.

The Sigfox network globally works within the ranges from 862 to 928 MHz. But not all RCs require such a wide range of operation.

	RC1	RC2	RC3	RC4	RC5	RC6	RC7
Uplink center frequency (MHz)	868.130	902.200	923.200	920.800	923.300	865.200	868.800
Downlink center frequency (MHz)	869.525	905.200	922.200	922.300	922.300	866.300	869.100

Uplink data rate (bit/s)	100	600	100	600	100	100	100
Downlink data rate (bit/s)	600	600	600	600	600	600	600
Sigfox recommended EIRP (dBm)	16	24	16	24	14	16	16
Specifics	Duty cycle 1% *	Frequency hopping **	Listen Before Talk ***	Frequency hopping **	Listen Before Talk ***		Duty cycle 1% *

* **Duty cycle** is 1% of the time per hour (36 seconds). For an 8 to 12 bytes payload, this means 6 messages per hour, 140 per day.

** **Frequency hopping**: The device broadcasts each message 3 times on 3 different frequencies. Maximum On time 400 ms per channel. No new emission before 20 s.

*** **Listen Before Talk**: Devices must verify that the Sigfox-operated 200 kHz channel is free of any signal stronger than -80 dBm before transmitting.


Sigfox's high limit EIRP recommendation is included in each column although regulations sometimes allow for more radiated power than the Sigfox recommendation.

Sigfox's recommendation is set to comply with the Sigfox technological approach of:


- Low current consumption
- Balanced link budget between uplink and downlink communication

5.2 Add a device to the Backend Sigfox

Step 1: Log in to the sigfox backend website




← → ↻ 🔒 backend.sigfox.com/auth/login




Remember me for one week ☐

Sign in

Step 2: Click on Device




Step 3: Click New → Select a group



Step 4: Fill in the required information

Note: Some of our products may not have end product certification in time, to add the product to Backend Sigfox please follow the steps below.

Click on the text as shown below




The screenshot shows the 'Device - New' form in the Sigfox Backend. The form is titled 'Device - New' and contains several input fields and checkboxes. The 'End product certificate' field is highlighted with a red box, and a red arrow points to it. The text 'Where can I find the end product certificate?' is written inside the box. The form also includes fields for Identifier (hex!), Name, PAC, Type, Lat, and Lng, as well as checkboxes for Subscription automatic renewal and Activable. The footer of the form contains the copyright information: 'Copyright © Sigfox - 9.11.1-Scd92a9-20201207.155212 - 302 - Terms and conditions / Cookie policy.'

Device information

Identifier (hex!)

Name

PAC

End product certificate 

Where can I find the end product certificate?


Type Available Tokens: 0

Lat (-90° to +90°)

Lng (-180° to +180°)





Map [Locate on map](#)

Subscription automatic renewal ☒

Activable ☒ 

Copyright © Sigfox - 9.11.1-Scd92a9-20201207.155212 - 302 - Terms and conditions / Cookie policy.

Check the box as shown below to register as a prototype

 DEVICE DEVICE TYPE USER GROUP   

Device - New

Device information

Identifier (hexl)

Name

PAC

End product certificate

Where can I find the end product certificate?

The device vendor should provide the end product certificate number. If not, please use the search bar below:

Otherwise you can contact your [Sigfox distributor service desk](#)
If the device has not obtained an end product certificate yet, then you can register is as a prototype.

☒ Register as a prototype (remaining prototypes which can be registered in your group: 1000)


Type Available Tokens: 0

Lat (-90° to +90°)

Lng (-180° to +180°)

Map [Locate on map](#)


Subscription automatic renewal ☒

Activable ☒ 

Copyright © Sigfox - 9.11.1-5cd92a9-20201207.155212 - 302 - [Terms and conditions](#) / [Cookie policy](#).

5.3 Measurement principle of Sigfox People Counter

5.3.1 Overview



5.3.1.1 MCU Counter counts people in and out

Normally MCU Counter will be in sleep state, PIR Sensor works with low current, Laser Sensor is in power off state.

When someone approaches, PIR Sensor will wake up MCU Counter → MCU Counter power on Laser Sensor →

Laser Sensor returns the measured distance value from the Laser Sensor (mounted on the ceiling) to the nearest obstacle down to the floor.

Dist_threshold mechanism:

- The sensor will measure the distance from the sensor (on the ceiling) to the floor, when there is an obstacle, the person is under the sensor, the sensor will measure the distance from the sensor to the obstacle, that person => will get the **DistX** value
- When **DistX < Dist_threshold**, the sensor detects that someone is standing below
- When **DistX > Dist_threshold + dist_hys**, the sensor confirms that no one is under

MCU Counter performs counting people in and out based on the principle of counting people in **below**.

When there are no people nearby, the MCU Counter will power off the Laser Sensor, and the MCU Counter will also sleep.

5.3.1.2 MCU Sigfox

Normally the Sigfox MCU sleeps.

When it comes to the sampling_rate cycle, the Sigfox MCU wakes up reading the Counters values from the MCU Counter. Read-in values include NRC_People_in, NRC_People_out, Dist_front_zone, Dist_back_zone.

The Sigfox MCU will calculate the RC_People_in, RC_People_out based on saving the last NRC_People_in, NRC_People_out values before sending to the Sigfox Server. $RC_People_in = NRC_People_in \text{ (recently read)} - NRC_People_in \text{ (saved)}$. $NRC_People_out = NRC_People_out \text{ (recently read)} - NRC_People_out \text{ (saved)}$.

If $(RC_People_in > count_threshold)$ or $(RC_People_out > count_threshold)$ then the Sigfox MCU will send the Uplink to the Sigfox Server. Then will delete RC_People_in and RC_People_out to 0. MCU Sigfox will save the last NRC_People_in, NRC_People_out values before sending to Sigfox Server.

When the cycle_send_data is reached, the Sigfox MCU wakes up reading the Counters values from the MCU Counter, calculates the new RC_People_in, RC_People_out and sends the Uplink to the Sigfox Server. Then will delete RC_People_in and RC_People_out to 0. MCU Sigfox will save the last NRC_People_in, NRC_People_out values before sending to Sigfox Server.


5.3.2 The principle of counting people

5.3.2.1 Overview

Counting people with the VL53L1X consists of using the multiple zones of the sensor receiving SPAD area, and of configuring it with two distinct fields of view (FoV), to alternatively get a ranging distance from them and consequently recognize the movements of a person. Using this method, the number of people occupying a meeting room, accessible from a reasonably narrow access, is known at all times by detecting the entrances and exits of the attendees.


By measuring and analyzing the distances of targets within the FoVs of a front and back zone (see figure below and Figure 3. Front and back zones), a simple algorithm can detect the direction a person crosses the area under the two FoVs. This algorithm "understands" that someone is under one of the FoV as long as the distance measured by the sensor under this FoV is between 0 and a threshold value specified in mm.

Figure 1. VL53L1X FoV divided in two subfields of view



From a timing perspective, the sensor alternatively ranges on each of the two zones, for a very short period of time in milliseconds. It is possible to determine in which direction a person crosses the area, depending in which order this person has been detected in the two zones, as shown in the figure below.

Figure 2. Person counting chronogram




5.3.2.2 Algorithm description

The counting algorithm example relies on a list of states that have to occur in a certain order to detect if a person has crossed the specified area and in which direction this area has been crossed. These states are stored in a list and compared to two default lists of states that represent how the area is crossed in two different directions. When no-one is seen in either of the two zones, the list of states is reset.

If we consider that a person detected in the front zone equals 2, and a person detected in the back zone equals 1, the algorithm adds the value of the two states and stores the result as soon as it changes.

Eventually, if the consecutive states in the list are 0, 1, 3, 2, 0 or 0, 2, 3, 1, 0 this means a person has been detected in one direction or the other, as described in Figure 4. List of status values.

Figure 3. Front and back zones



The diagram shows a black silhouette of a person walking to the right, carrying a bag. A blue cone of vision originates from the person's head. The base of this cone on the ground is divided into two overlapping circular regions. The region directly in front of the person is labeled 'Front zone' in red text. The region behind the person is labeled 'Back zone' in red text. The two zones overlap in the area immediately behind the person's feet.

Front

Back

Sum

0 2 3 1 0

Path track

0
0,2
0,2,3
0,2,3,1
0,2,3,1,0
0

A person has crossed the area in a certain direction

Front

Back

Sum

0 1 3 2 0


Path track

0
0,1
0,1,3
0,1,3,2
0,1,3,2,0
0

A person has crossed the area in the other direction

The algorithm validates a crossing event only when a person has fully crossed the two zones. It does not validate the event when the person remains for a long time under the FoV or when the person decides to return from the place he came from.

Figure 5. Hysteresis principle




A threshold needs to be defined, which is achieved after having ranged on the flooring material over a significant number of samples. In fact, the threshold should be chosen so that all the measured distances (when ranging the floor) are greater than this threshold. We recommend that at installation of the application, an autocalibration routine is launched to calculate the threshold. This is because flooring material can be different in many locations.

Figure 6. People counting at 2345 mm distance from the floor. The distance between the sensor and the floor is 2345 mm, and as the minimum distance measured by the sensor is 2290 mm, the threshold is thus less than 2290 mm.

Note: This calibration should be performed in the worst ambient light conditions, to maximize the jitter and obtain a threshold that is relevant to all possible ambient lighting conditions the counting setup is exposed to.

Figure 6 People counting at 2345 mm distance from the floor



5.4 Payload Data

The following is the format of payload data will be sent to Sigfox server.


5.4.1 Payload for uplink 12 bytes

Sensor type (1 byte)	Status (1 byte)	NRC_People_in (2 bytes)	NRC_People_out (2 bytes)	RC_People_in (1 byte)	RC_People_out (1 byte)	Dist_front_zone (2 bytes)	Dist_back_zone (2 bytes)
-------------------------	--------------------	----------------------------	-----------------------------	--------------------------	---------------------------	------------------------------	-----------------------------

Meaning of Data in the Payload

Data	Size (byte)	Bit	Format	Meaning
Sensor type = 0x13	1	all	UInt8	Sensor type = 0x13 means Sigfox People Counter
Status: battery level	1	Bit 7 and 6	UInt8	Battery capacity in 04 levels 11: battery level 4 (99%) 10: battery level 3 (60%) 01: battery level 2 (30%) 00: battery level 1 (10%)
Status: error		Bit 5 and 4		Node status 01: hardware sensor error 00: no error
NRC_People_in	2	all	UInt16	Non-resettable counter
NRC_People_out	2	all	UInt16	Non-resettable counter
RC_People_in	1	all	UInt8	Reset to 0 after sending to Sigfox server
RC_People_out	1	all	UInt8	Reset to 0 after sending to Sigfox server

Dist_front_zone	2	all	Uint16	Distance of front zone
Dist_back_zone	2	all	Uint16	Distance of back zone



5.4.2 Payload for Downlink, length is 8 bytes

⚠ The Sigfox node is only able to receive max 04 downlinks a day, each downlink will be waiting in every 06 hours.

User can set the down link data in Sigfox back-end system in advance, whenever the Sigfox node connected to base stations and with downlink waiting is enable at that time (one time in 6 hours), the downlink data will be loaded to Sigfox node.

The downlink data can be any configuration parameter.

⚠ **Please pay attention when send downlink data.** If there was a mistake in sending wrong data, it would cause the Sigfox node not working properly and user need to configure it by **offline cable!!!**

Downlink payload format:

Prm_adr (1 byte)		Prm_len (1 byte)	Prm_value (6 bytes)
Prm_name	Prm_adr	Prm_len	Comment
cycle_send_data	0x12	0x04	
Count_threshold	0x44	0x02	
Dist_threshold	0x46	0x02	

📌 Examples of Downlink data to configure the Sigfox node

Example 1: Write down cycle_send_data = 30 minutes

Convert minutes to seconds: **30 minutes = 30 *60 = 1800 seconds**

Convert **1800** from **DEC** to **HEX** => **0x00000708** (4 bytes)

=> Downlink will be **1204000007080000**, where is:


Prm_adr	Prm_len	Prm_value	(remainder doesn't matter)
12	04	00000708	0000

Example 2: Write down Count_threshold = 10

Convert 10 from DEC to HEX to **0x000A** (2 bytes)

=> Downlink will be **4402000A00000000**, where is:

Prm_adr	Prm_len	Prm_value	(remainder doesn't matter)
44	02	000A	00000000



6. Offline configuration

Using the configuration cable to connect to the sensor as below picture.



Serial port configuration on computer: **9600** baud, **None** parity, **1** stop bit.

⚠ Reading data by **Function 3**.

Writing data by **Function 16**.

During connection with Modbus configuration tool, the Sigfox node will send all data in realtime: Battery, Battery level,

Vref, Button status, reed switch status, PCB temperature, Measured value, alarm status.

Step to configure & check data:

NOTE:



The Modbus configuration can be done in the first **60s** after power up the Sigfox node. After 60s, if user can not finish the configuration, user need to reset the power of Sigfox node again, by removing battery in at least 15s.

Step 1: Install the Modbus Configurator Software in the link below

<https://filerun.daviteq.com/wl/?id=yDOjE5d6kqFIGNVVIMdFg19Aad6aw0Hs>

How to use the Modbus configuration software


Step 2: Plug the configuration cable to Computer via **USB** port;



Step 3: Open the housing by using flat head screws to push into 2 reed joints;




Step 4: Plug the connector to the configuration port;



Step 5: Import the configuration file by importing the csv file: Go to MENU:FILE / **Import New** / => select the file with name CONFIGURATION TEMPLATE FILE FOR SIGFOX.csv (in the link below). Then click **Connect**;



CONFIGURATION TEMPLATE FILE FOR SIGFOX WSSFC-LPC.csv



6.1 Data table

Modbus Register (Decimal)	Modbus Register (Hex)	Function Code	# of Registers	Description	Range	Default	Format	Property	Comment
0	0	3	2	device info			string	Read	Product name
2	2	3	4	firmware version			string	Read	
6	6	3	2	hardware version			string	Read	

8	8	3	2	device ID			hex	Read	Product ID
10	A	3	4	device PAC			hex	Read	Product PAC

6.2 Configuration table

Modbus Register (Decimal)	Modbus Register (Hex)	Function Code (Read)	Function Code (Write)	# of Registers	Description	Range	Default	Format	Property	Comment
270	10E	3	16	1	Radio Configuration	1, 2, 4	4	uint16	Read/Write	RC zones selection 1, 2, 4 is RCZ1, RCZ2, RCZ4
271	10F	3	16	1	tx_power		20	int16	Read/Write	RF Tx power
272	110	3	16	1	tx_repeat	0-1	1	uint16	Read/Write	Number of repeat, 0: 1 time, 1: 3 repeats
273	111	3	16	1	downlink_flag	0-1	1	uint16	Read/Write	1: enable Downlink, 0: disable Downlink
274	112	3	16	2	cycle_send_data	sec	3600	uint32	Read/Write	Data sending cycle, in seconds
280	118	3	16	2	sampling_rate	sec	120	uint32	Read/Write	Sensor/Input 1 sampling rate, in seconds
324	144	3	16	1	count_threshold		20	hex	Read/Write	threshold count on how many people send sigfox

325	145	3	16	1	distThreshol		1600	uint16	Read / Write	<p>Threshold setting for laser sensor to distinguish between when people are present and when no one is standing under the sensor. The laser sensor will measure the distance value from the sensor (ceiling) to the floor.</p> <ul style="list-style-type: none"> When there are people, the measured laser sensor value < distThresh When there is no person, the measured laser sensor value > distThresh
326	146	3	16	1	distHys		100	uint16	Read / Write	<p>Hys of distThreshol</p>
327	147	3	16	1	inter_meas_		48	uint16	Read / Write	<p>The sampling time of the sensor laser</p>

7. Installation


7.1 Locate the good place for Radio signal

To maximize the distance of transmission, the ideal condition is Line-of-sight (LOS) between the Sigfox sensor and Base station. In real life, there may be no LOS condition. However, the Sigfox sensor still communicate with Base station, but the distance will be reduced significantly.

ATTENTION:

DO NOT install the Sigfox sensor or its antenna inside a completed **metallic** box or housing, because RF signal can not pass through metallic wall. The housing is made from Non-metallic materials like plastic, glass, wood, leather, concrete, cement...is acceptable.

SYSTEM ARCHITECTURE



WSSFC-LPC-H3.PNG


7.2 Mounting

- Installation method:** Mount to the ceiling
- Locate the mounting position at the entrance where people pass by, and out of direct sunlight
- The direction of the triangle is the direction of counting people entering as specified in the payload
- Determine the correct orientation to install the bottom cover to the ceiling in the correct direction

WARNING:


- Avoid placing hands or heavy objects on the laser sensor surface or the PIR sensor surface, as this may cause damage to the device;
- Periodically use a clean cloth moistened with 70 degrees of alcohol to wipe the surface of the 2 sensors to keep the sensor clean and accurate.

Step 1: Determine the direction of people entering the room of the sensor



Step 2: Mount the bottom housing of the sensor to the ceiling by fasten the 2 screws to the ceiling located at the 2 diagonal corners of the bottom cover.

- ⚠ Use the 2 screws that are included to be used to attach the sensor to surfaces such as **Wood, composite plastic**.
- ⚠ If the ceiling surface is made of plaster, it is recommended to use a special **insert** so that the device can firmly adhere to the ceiling surface. **Avoid dropping the device.**



Step 3: Attach the top and bottom housings (note the 2 reed joint)

- ⚠ Fit the main body to the bottom cover in the correct direction: the **2 reed joints** on the bottom cover should fit into the main body on the side labeled with the device.
- ⚠ Make sure that the main body is fully engaged with the bottom cover, then release the hand.



7.3 Battery installation

RECOMMENDED BATTERIES

E91 AA Alkaline battery



-18 .. + 60 oC working temperature

10-year shelf life

3000 mAh Capacity

Price: 1X

L91 AA Lithium battery



-40 .. + 60 oC working temperature

20-year shelf life


3500 mAh Capacity

Price: 3.5X

WSSFC-LPC-H5.PNG

Steps for battery installation:

Step 1: Using flat head screws to push into 2 reed joints




Step 2: Open the housing, then insert 06 x AA 1.5VDC battery, please take note the poles of the battery

ATTENTION:



REVERSED POLARITY OF BATTERIES IN 10 SECONDS CAN DAMAGE THE SENSOR CIRCUIT!!!





Step 3: Insert the top plastic housing (**Please note the 2 reed joint**)



8. Troubleshooting

No.	Phenomena	Reason	Solutions
1	Node does not send RF to base station periodically, LED does not blink	<ul style="list-style-type: none"> No power supply or battery ran out Configuration sending cycle is incorrect 	<ul style="list-style-type: none"> Check that the battery is empty or not installed correctly Check the power supply Check the send cycle configuration
2	Node does not send RF to base station according to the alarm, LED does not blink	<ul style="list-style-type: none"> The alarm configuration is incorrect Running out of the number of alarms set for the day 	<ul style="list-style-type: none"> Check alarm configuration Check the configuration for the maximum number of alarms per day

3	Node does not send RF to base station when activated by the magnetic switch, LED does not blink	<ul style="list-style-type: none"> • Magnetic switch has malfunctioned • Or place the Magnet key not right position 	<ul style="list-style-type: none"> • Locate the correct position for magnet key • Read the status of the magnetic switch via modbus (when powering or attaching the battery) to see if the magnetic switch is working.
4	Node has blinked LED when sending RF but the base station cannot received	<ul style="list-style-type: none"> • Out of the number of RF packages of uplink per day (140 packages / day) 	<ul style="list-style-type: none"> • Check on the base station whether the event message exceeds the number of RF packets
5	Node has sent RF but the LED does not blink	<ul style="list-style-type: none"> • LED malfunction 	<ul style="list-style-type: none"> • Contact manufacturer
6	The measurement values from sensor do not change, keep constant values for long time	<ul style="list-style-type: none"> • Sensor got failure • Sensor cable broken • Sensor connector is not connected firmly 	<ul style="list-style-type: none"> • Check sensor cable and connector • If the issue is still exist, please contact manufacturer for warranty or replace new sensor
7	The node does not send RF and the RF module is hot	<ul style="list-style-type: none"> • Insert the battery in the wrong direction • Electronics got problem 	<ul style="list-style-type: none"> • Check battery polarity
8	RSSI is weak and often loses data	<ul style="list-style-type: none"> • Distance between Node and Base station is far or there are many obstructions • Connection to Antenna problem 	<ul style="list-style-type: none"> • Check location of Sigfox node and distance to base station • Check the antenna connector in the PCB

9. Support contacts



Daviteq Technologies Inc
 No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam.
 Tel: +84-28-6268.2523/4 (ext.122)
 Email: info@daviteq.com | www.daviteq.com

🕒 Revision #19
 ★ Created Sun, Aug 8, 2021 10:54 PM by [Kiệt Anh Nguyễn](#)
 ✎ Updated Wed, Jan 24, 2024 6:58 AM by [Phi Hoang Tran](#)