HTML table for LED indication 2

Uplink message	Pre-condition	Action	Led Status	Buzzer Status	Activiti
FORCE_DATA	Any state	Move Magnet Key to contact point of REED SWITCH. Led blink SKY BLUE and buzzer beep 1 time, move Magnet Key away.	Blink SKY BLUE	Beep 1 time	See FW specs
PARAMETERS_UPDATE	Any state	Move Magnet Key to contact point of REED SWITCH. Led blink SKY BLUE and buzzer beep 1 time. Then hold Magnet Key 5s, Led blink PURPLE and buzzer beep 2 times, move Magnet Key away.	Blink PURPLE	Beep 2 times	See FW specs

Revision #2
Created Mon, Sep 11, 2023 8:10 PM by Phan Van Luc
Updated Mon, Sep 11, 2023 8:18 PM by Phan Van Luc