

HTML table for LRW connection

| Field | Input field |
|------------|--|
| Name | As user-defined |
| LRR-UUID | Contact the Tektelic Support to get LRR-UUID for Thingpark. Details at link Instruction to get info from the LRR gateway |
| RF region | Site frequency plan (US915, EU868..) |
| Public Key | Contact the Tektelic Support to get LRR-UUID for Thingpark. Details at link Instruction to get info from the LRR gateway |

🕒 Revision #12
★ Created Tue, Sep 5, 2023 1:56 AM by [Phan Van Luc](#)
✎ Updated Tue, Sep 5, 2023 9:48 PM by [Phan Van Luc](#)