

# HTML table for LRW connection

Field	Input field
Name	As user-defined
LRR-UUID	Contact the Tektelic Support to get LRR-UUID for Thingpark. Details at link <a href="#">Instruction to get info from the LRR gateway</a>
RF region	Site frequency plan (US915, EU868..)
Public Key	Contact the Tektelic Support to get LRR-UUID for Thingpark. Details at link <a href="#">Instruction to get info from the LRR gateway</a>

---

🕒 Revision #12

★ Created Tue, Sep 5, 2023 1:56 AM by [Phan Van Luc](#)

✎ Updated Tue, Sep 5, 2023 9:48 PM by [Phan Van Luc](#)