# HTML table for LRW connection

| Field | Input field |
| --- | --- |
| Name | As user-defined |
| LRR-UUID | Contact the Tektelic Support to get LRR-UUID for Thingpark. Details at link<br>Instruction to get info from the LRR gateway |
| RF region | Site frequency plan (US915, EU868..) |
| Public Key | Contact the Tektelic Support to get LRR-UUID for Thingpark. Details at link<br>Instruction to get info from the LRR gateway |

Revision #12
Created Tue, Sep 5, 2023 1:56 AM by Phan Van Luc
Updated Tue, Sep 5, 2023 9:48 PM by Phan Van Luc