

USER GUIDE FOR LONG RANGE WIRELESS CO-ORDINATOR WS433-CL

WS433-CL-MN-EN-01

FEB-2020

This document is applied for the following products

SKU	WS433-CL	HW Ver.	2.4	FW Ver.	1.9
Item Code	WS433-CL-04	Wireless Sensor Co-ordinator with external antenna 0 dbi, M12-Female connector, 4-pin, coding A, RS485 ModbusRTU			
	RS485-FM12-USB-1	RS485/USB multi-purpose Configuration cable** with connector m12 male, female and flying leads, with Power adapter 12VDC/2.0A			


1. Functions Change Log

HW Ver.	FW Ver.	Release Date	Functions Change
2.4	1.9	NOV-2019	

2. Introduction

WS433-CL is a wireless co-ordinator in a wireless sensor network, a high-performance type. It is able to configure the parameters for all end nodes in the network. By the Sub-Ghz technology from Texas Instruments, it is easy to establish multiple networks in same area without interference or channel conflict. One co-ordinator can handle maximum of 40 end nodes in its network. LOS transmission distance up to 6000m. The WS433-CL also has the option of adding an IoT Gateway built-in to facilitate remote configuration and diagnostics, as well as remote monitoring and control via any IIoT platform. The installation and configuration is very simple. Setting up a wireless sensor network has never been this easy.

LONG RANGE WIRELESS COORDINATOR WS433-CL



WS433-CL-H1.PNG



3. Specification

Communication	RS485
Data speed	Up to 50kbps
Transmission distance	LOS 6000m @ 50 kbps (antenna height is 4m minimum)
Antenna	Standard external antenna 0 dbi, option 3dbi, 6dbi, 9dbi
Power supply	7..48 Vdc @ 500mA max
Electrical connector	M12-female, 4-pin A-coding
RF frequency band	Free license ISM 433.92Mhz (for others 868, 915, 920Mhz, refer related datasheets)
Ready to comply	ETSI EN 300 220, EN 303 204 (Europe) FCC CFR47 Part15 (US), ARIB STD-T108 (Japan)**
Vietnam Type Approval Certification	QCVN 73:2013/BTTTT, QCVN 96:2015/BTTTT (DAVITEQ B00122019)
Security Standard	AES-128
Operating temperature	-40oC..+85oC
Housing	Aluminum + Polycarbonate, IP67
Included accessories	Mounting bracket for wall mount
Product dimension	H106 x W73x D42 mm (excluded antenna)
Net weight	190 grams
Box dimension	W160 x D150 x H100 mm

Gross weight

< 300g

4. Product Pictures


LONG RANGE WIRELESS COORDINATOR
WS433-CL



WS433-CL-H1.PNG




CONNECT WIRELESS SENSORS TO
any PLC or HMI



WS433-CL-H2.PNG

CONNECT WIRELESS SENSORS TO
any SCADA or IoT Platform




WS433-CL-H3.PNG

CONNECT WIRELESS SENSORS TO
GLOBIOTS Platform




WS433-CL-H4.PNG


**DIMENSION DRAWING WIRELESS CO-ORDINATOR
WS433-CL**



**DIMENSION DRAWING WIRELESS CO-ORDINATOR
WS433-CL**



HIGH GAIN OMNI ANTENNA 3DBI & 6DBI



USB-RS485 CONFIGURATION CABLE



5. Operation Principle

5.1 Add sensors node to Co-ordinator WS433-CL


5.1.1. Add Sensor Node ID automatically

INSTALL ANTENNA



WS433-CL-H10.PNG

PIN ASSIGNMENT & WIRING



WS433-CL-H18.PNG

Step 1: After supplying power the Co-ordinator via M12 connector, the Node ID must be registered within the first 5 minutes, up to 40 WS.

Step 2: Bring the wireless sensor closer to the Co-ordinator's antenna then take off the wireless sensor battery, wait for 5s then insert the battery again. If:

- Buzzer plays **1 peep** sound, LED blink 1 time, that means registering Node ID on Co-ordinators **successfully**.
- Buzzer plays **2 peep** sounds, LED blink 2 times, that this Node ID is **already registered**.

If you do not hear the "Peep" sound, please disconnect the power the co-ordinator, wait a few minute and try again.

Node id added in this way will be written to the **smallest node_id_n** address which is = **0**.

Set **Rssi_threshold** (see **RF MODE CONFIG** (in the **Modbus Memmap of WS433-CL**), default **-25**): The case if Co-ordinator is on high position and need to add node sensor. We set the sensor as close as possible and set the **Rssi_threshold** to **-80, -90** or **-100** to increase the sensitivity to allow WS433-CL-04 can add sensors at a longer distance. After that, perform 2 steps of adding sensors and then reset **Rssi_threshold** = **-25**.

Enb_auto_add_sensors configuration (see **RF MODE CONFIG** (in the **Modbus Memmap of WS433-CL**)): In case you do not want to turn off the power WS433-CL, you can set **Enb_auto_add_sensors** = **1**, this way we have 5 minutes to add nodes (add up to 40 nodes) . After 5 minutes **Enb_auto_add_sensors** will automatically = **0**.

Memmap resgisters

You can download Modbus Memmap of WS433-CL with the following link:

<https://filerun.daviteq.com/wl/?id=BKEaUzdArkoc0Hc7nfpRShdPVT0VrQqZ>

5.1.2 Add sensor node into WS433-CL-04 (1) through intermediate WS433-CL-04 (2) and Modbus

IN CASE the sensor need to be added to WS433-CL-04 (1) has been installed in a high position, the sensor cannot be brought close to WS433-CL-04 (1).

First, you need to prepare



Computer



RS485
Configuration Cable



Power Adapter 12-24VDC

WS433-CL-H9.PNG

For example: WS433-CL-04 **(1)** has connected 1 sensor node and needs to connect 1 more sensor node WS433-M12F. So we use a WS433-CL-04 **(2)** to configure the 2nd sensor connected to WS433-CL-04**(1)**

Step 1: Add Sensor Node ID automatically to WS433-CL-04 **(2)** (steps as above video)

Step 2: Use the RS485 configuration cable to communicate with the Co-ordinator WS433-CL-04**(2)** via Modbus software **(in the link below)**, then **write** the ID of the Co-ordinator WS433-CL-04**(1)** into "**Co-ordinator id**" and **sync** with the sensor node

Daviteq Modbus Configuration Tool: <https://filerun.daviteq.com/wl/?id=yDOjE5d6kqFIGNVVIMdFg19Aad6aw0Hs>



Template WS433-CL-Template Adding Wireless Sensor: <https://filerun.daviteq.com/wl/?id=cuVB3swIFLoYbiZeK11hpO0w8NW2vU7w>



How to use the Modbus configuration software

CONNECT CO-ORDINATOR TO RS485 - CONFIGURATION
CABLE via M12 CONNECTOR




WS433-CL-H12.PNG

CONNECT RS485 - CONFIGURATION
TO COMPUTER via USB




WS433-CL-H13.PNG


- Unzip file and run file application **Daviteq Modbus Configuration Tool Version**





- Choose **COM Port** (the Port which is USB cable plugged in)
- Set the **BaudRate: 9600, Parity: none**




- Click "**Connect**" until the Status displays "**disconnected**" to "**connected**". It means the WS433-CL-04 is being connected with computer;
- Next, we need to import the configuration file for WS433-CL-04 by importing the csv file: Go to **MENUEFILE / Import New / =>** select the file with name **WS433-CL-Template Adding Wireless Sensor.csv** (after unzip file).



- We can see that WS433-CL-04 (2) has connected the sensor to the sensor's id node s/n and the co-ordinator id s/n syncs with the sensor



- In the row Co-ordinator id sync to node 1, we change the co-ordinator id WS433-CL-04(2) of sensor node to co-ordinator id WS433-CL-04 (1) by **Uncheck Func 3** => change **Func** from **3** to **16**



- Type in **Setting Value** the co-ordinator id of WS433-CL-04(1) => **Check** Func 16 if **Read Value** show **OK** which mean it's wrote successful

Daviteq Modbus Configuration Tool Version 1.2

FILE EDIT

Port: COM5 BaudRate: 9600 Parity: none

Status: connected tx rx

tx: 40524 rx: 36681

ok: 36680

crc: 1

tmo: 3843

Run Program 16/03_11:39 disconnected 16/03_11:39 disconnected 16/03_11:39 connected

	Func	Reg	Num	Format	Prm Name	Setting Value	Read Value	CLEAR	Ex
37	<input checked="" type="checkbox"/>	3	343	2	uint	Node id 36	0		
38	<input checked="" type="checkbox"/>	3	345	2	uint	Node id 37	0		
39	<input checked="" type="checkbox"/>	3	347	2	uint	Node id 38	0		
40	<input checked="" type="checkbox"/>	3	349	2	uint	Node id 39	0		
41	<input checked="" type="checkbox"/>	3	351	2	uint	Node id 40	0		
42	<input type="checkbox"/>	16	402	2	uint	Co-ordinator id syn...	1601211440	1601211569	
43	<input checked="" type="checkbox"/>	3	442	2	uint	Co-ordinator id syn...	0		
44	<input checked="" type="checkbox"/>	3	482	2	uint	Co-ordinator id syn...	0		
45	<input checked="" type="checkbox"/>	3	522	2	uint	Co-ordinator id syn...	0		
46	<input checked="" type="checkbox"/>	3	562	2	uint	Co-ordinator id syn...	0		
47	<input checked="" type="checkbox"/>	3	602	2	uint	Co-ordinator id syn...	0		
48	<input checked="" type="checkbox"/>	3	642	2	uint	Co-ordinator id syn...	0		
49	<input checked="" type="checkbox"/>	3	682	2	uint	Co-ordinator id syn...	0		
50	<input checked="" type="checkbox"/>	3	722	2	uint	Co-ordinator id syn...	0		

Daviteq Modbus Configuration Tool Version 1.2

FILE EDIT

Port: COM5 BaudRate: 9600 Parity: none

Status: connected tx rx

tx: 47130 rx: 43287

ok: 43286

crc: 1

tmo: 3843

Run Program 16/03_11:39 disconnected 16/03_11:39 disconnected 16/03_11:39 connected

	Func	Reg	Num	Format	Prm Name	Setting Value	Read Value	CLEAR	Ex
37	<input checked="" type="checkbox"/>	3	343	2	uint	Node id 36	0		
38	<input checked="" type="checkbox"/>	3	345	2	uint	Node id 37	0		
39	<input checked="" type="checkbox"/>	3	347	2	uint	Node id 38	0		
40	<input checked="" type="checkbox"/>	3	349	2	uint	Node id 39	0		
41	<input checked="" type="checkbox"/>	3	351	2	uint	Node id 40	0		
42	<input checked="" type="checkbox"/>	16	402	2	uint	Co-ordinator id syn...	1601211440	1601211569	
43	<input checked="" type="checkbox"/>	3	442	2	uint	Co-ordinator id syn...	0		
44	<input checked="" type="checkbox"/>	3	482	2	uint	Co-ordinator id syn...	0		
45	<input checked="" type="checkbox"/>	3	522	2	uint	Co-ordinator id syn...	0		
46	<input checked="" type="checkbox"/>	3	562	2	uint	Co-ordinator id syn...	0		
47	<input checked="" type="checkbox"/>	3	602	2	uint	Co-ordinator id syn...	0		
48	<input checked="" type="checkbox"/>	3	642	2	uint	Co-ordinator id syn...	0		
49	<input checked="" type="checkbox"/>	3	682	2	uint	Co-ordinator id syn...	0		

Daviteq Modbus Configuration Tool Version 1.2

FILE EDIT

Port: COM5 BaudRate: 9600 Parity: none

Status: connected tx rx

tx: 41264 rx: 37421

ok: 37420


crc: 1

tmo: 3843

Run Program 16/03_11:39 disconnected 16/03_11:39 disconnected 16/03_11:39 connected

	Func	Reg	Num	Format	Prm Name	Setting Value	Read Value	CLEAR	Ex
37	<input checked="" type="checkbox"/>	3	343	2	uint	Node id 36	0		
38	<input checked="" type="checkbox"/>	3	345	2	uint	Node id 37	0		
39	<input checked="" type="checkbox"/>	3	347	2	uint	Node id 38	0		
40	<input checked="" type="checkbox"/>	3	349	2	uint	Node id 39	0		
41	<input checked="" type="checkbox"/>	3	351	2	uint	Node id 40	0		
42	<input checked="" type="checkbox"/>	16	402	2	uint	Co-ordinator id syn...	1601211440	OK	
43	<input checked="" type="checkbox"/>	3	442	2	uint	Co-ordinator id syn...	0		
44	<input checked="" type="checkbox"/>	3	482	2	uint	Co-ordinator id syn...	0		
45	<input checked="" type="checkbox"/>	3	522	2	uint	Co-ordinator id syn...	0		
46	<input checked="" type="checkbox"/>	3	562	2	uint	Co-ordinator id syn...	0		
47	<input checked="" type="checkbox"/>	3	602	2	uint	Co-ordinator id syn...	0		
48	<input checked="" type="checkbox"/>	3	642	2	uint	Co-ordinator id syn...	0		
49	<input checked="" type="checkbox"/>	3	682	2	uint	Co-ordinator id syn...	0		
50	<input checked="" type="checkbox"/>	3	722	2	uint	Co-ordinator id syn...	0		



- Change **Func 16** to **3** then **Check** to read the value we just wrote in => if **Read Value** show the co-ordinator id of WS433-CL-04 (**1**) that mean the sensor node has sync with WS433-CL-04(**1**)



Step 3: Using iConnector, Modbus on Globiots communicating with WS433-CL(1) to write node ID of sensor node to node address id = 0 followed by node id already in **“Adding Wireless sensor (in the Modbus Memmap of WS433-CL)”** area.

Ex: In globiots, create a parameter with the address space x3000 then create a modbus command according to the memmap file.

- Function **3**: Read holding registers
- Function **4**: Read input registers
- Function **16**: Preset Multiple registers



- Next **add container** on the dashboard, then add the parameters created to container as button **Write ID Node 2**

globiots

by deviateq

Management

Configuration

Administrators

Home

Dashboard

+

ADDING SENSOR

SENSOR MONITORING

SENSOR MONITORING

Reading Sensor Node

13:51

Adding Sensor Node

13:51

Number of Node	1	Name	Write ID Node
Sensor Node 1	422000128	Sensor Node 1	Write ID Node 1
Sensor Node 2	0	Sensor Node 2	Write ID Node 2

- Click **"Write ID Node 2"** to write the id of node 2 to the co-ordinator WS433-CL-04

globiots

by deviateq

Management

Configuration

Administrators

Home

Dashboard

+

ADDING SENSOR

SENSOR MONITORING

SENSOR MONITORING

Reading Sensor Node

14:19

Adding S

Number of Node	1	Name	
Sensor Node 1	422000128	Sensor Node 1	Write ID Node 1
Sensor Node 2	0	Sensor Node 2	Write ID Node 2

Set data to parameter 'WRITE ID NODE 2'

Value

190000062

Cancel

OK

globiots

by deviateq

Management

Configuration

Administrators

Home

Dashboard

+

ADDING SENSOR

SENSOR MONITORING

SENSOR MONITORING


Reading Sensor Node

14:34

Adding Sensor Node

14:34

Number of Node	2	Name	Write ID Node
Sensor Node 1	422000128	Sensor Node 1	Write ID Node 1
Sensor Node 2	190000062	Sensor Node 2	Write ID Node 2



5.2 Configuring the co-ordinator WS433-CL

- **Num of Node** will indicate the number of nodes managed by WS433-CL.
- Every time a node is **added**, the Num of Node will **increase** by 1.
- Every time a node is **deleted**, the Num of Node is **reduced** by 1.
- Writing Num of Node = 0 will **delete all** 40 node ids to 0.
- If you want to delete a node id, then write it = 0 with the **Write** function is **16** and the **Read** function is **3**.

First, you need to prepare



Computer



RS485
Configuration Cable



Power Adapter 12-24VDC

WS433-CL-H9.PNG

Step 1: Connect Antenna, RS485 - configuration cable and power supply co-ordinator

INSTALL ANTENNA



WS433-CL-H10.PNG

CONNECT CO-ORDINATOR TO RS485 - CONFIGURATION CABLE via M12 CONNECTOR



WS433-CL-H12.PNG

SUPPLY POWER 12-24VDC



WS433-CL-H11.PNG

CONNECT RS485 - CONFIGURATION TO COMPUTER via USB



WS433-CL-H13.PNG

Step 2: Open Modbus tool on PC





- You can download Daviteq Modbus Configuration Tool with the following link:

<https://filerun.daviteq.com/wl/?id=yDOjE5d6kqFIGNVVIMdFg19Aad6aw0Hs>


Template File: <https://filerun.daviteq.com/wl/?id=hgrjOg3wwvyrvAZ54p8iZiFpDyXTcnc>

How to use the Modbus configuration software


- Unzip file and run file application "mb_master 1.1"

Name	Date modified	Type	Size
 common_lib.dll	2019-03-08 17:08	Application exten...	20 KB
 master_lib.dll	2019-03-14 10:27	Application exten...	9 KB
 mb_lib.dll	2019-03-08 17:08	Application exten...	232 KB
 mb_master 1.1	2019-07-01 10:58	Application	8 KB

- Choose **COM Port** (the Port which is USB cable plugged in)
- Set the **BaudRate: 9600, Parity: none**



- Click "**Connect**" until the Status displays "**disconnected**" to "**connected**". It means the WS433-CL-04 is being connected with computer;
- Next, we need to import the configuration file for WS433-CL-04 by importing the csv file: Go to **MENUEFILE / Import New** / => select the **template file (csv)**.



Step 2: Check information of sensor.

5.3 Hall sensor and button function

Push Button or Hall sensor for the first 5 minutes when power is available:

- Press and hold the push button or bring the magnet near the Hall sensor for **2s** => see the LED blink **once** or the buzzer will ring **1 Beep** => release the push button or take the magnet out to set RF data rate **RF50 kbps**
- Press and hold the push button or bring the magnet near the Hall sensor for **5s** => see the LED blink **twice** or the buzzer beep **2 Beep** => release the push button or take the magnet out to set RF data rate **RF625 bps**
- Press and hold the push button or bring the magnet near the Hall sensor for **10s** => see the LED blinking **3 times** or the buzzer buzzes **3 Beep** => release the push button or take the magnet to perform the **User factory reset** (User factory reset = reset frequency, RF transmit power, data rate, Node ID of 40 WS, Modbus operating parameters, compare time for data status).
- If it takes more than **30 seconds**, the button will be **deactivated**.

Reset default Co-ordinator:

- Frequency: **433.92 MHz**
- RF transmit power: **15 dBm**
- RF data rate: **50 kbps**
- Modbus: address = **1**, Baudrate = **9600**, Parity = **none**
- Num of Node = **0**, Node ID 40 nodes = **0**
- Compare time: **15, 30, 45, 60, 300, 600, 900, 1800**
- cmp_threshold = **630**
- rssi_threshold = **-25**

5.4 Manage data sent from nodes (up to 40 nodes)

LED will reverse state when WS433-CL receives RF packet from sensor node.

When WS433-CL receives data packet from node then WS433_CL will send ACK confirm. If the node does not receive the ACK, it will send the data packet one more time.

5.4.1 Data packet consists of 46 bytes:

Parameter	Byte Size	Format	Meaning
Battery	2	Uint16	<ul style="list-style-type: none"> High byte "spare", low byte is % battery capacity. Battery capacity has 4 levels: 10%, 30%, 60%, 99%.
1st - Parameter	4	vary	<ul style="list-style-type: none"> The measured value of the main parameter. Depending on the type of sensor, the measurement value is temperature, humidity, pressure difference, pressure, AC current measurement, digital input, mA, volt, relay, ... Depending on the measurement parameters, the data type will be different, described specifically in the documentation of that sensor.
SensorStatus	2	Byte	<ul style="list-style-type: none"> High byte indicates "ERROR". Byte low indicates "Type SENSOR".
2 nd -Parameter	4	vary	<ul style="list-style-type: none"> It is the measurement value of the auxiliary parameter (if have any). Depending on the sensor type, the measurement value is temperature, ... Depending on the measurement parameters, the data type will be different, described specifically in the documentation of that sensor. There may be more than one auxiliary parameter, depending on the sensor type. Refer to sensor documentation for details.
Logic status of Parameter	2	Uint16	<ul style="list-style-type: none"> Logic status of Parameter = Logic status 1 & Logic status 2. If the measurement value (eg temperature, humidity, current, etc.) of the sensor > high threshold then Logic status = 1, Logic status = 0 when the measured value of the sensor is < low threshold. High threshold 1, Low threshold 1, High threshold 2, Low threshold 2 are configured.
1 st - TimerUp	4	Uint32	Calculate the cumulative time when Logic status 1 = 1. The timer value is not saved when the sensor loses power.
1 st - TimerDown	4	Uint32	Calculate the cumulative time when Logic status 1 = 0. The timer value is not saved when the sensor loses power.
1 st - RisingEdge Counter	4	Uint32	Calculate the total accumulated times when Logic status 1 = 1. The Counter value is not saved when the sensor loses power.
1 st - FallingEdge Counter	4	Uint32	Calculate the total accumulated times when Logic status 1 = 0. The Counter value is not saved when the sensor loses power.

2 nd - TimerUp	4	Uint32	Calculate the total accumulated time when Logic status 2 = 1. The timer value is not saved when the sensor loses power.
2 nd - TimerDown	4	Uint32	Calculate the total accumulated time when Logic status 2 = 0. The timer value is not saved when the sensor loses power.
2 nd - RisingEdge Counter	4	Uint32	Calculate the total accumulated times when Logic status 2 = 1. The Counter value is not saved when the sensor loses power.
2 nd - FallingEdge Counter	4	Uint32	Tính tổng số lần cộng dồn khi Logic status 2 = 0. Giá trị Counter không có lưu khi cảm biến mất nguồn.

5.4.2 Status bytes of sensor Node

- Hi-Byte is error code

Error code	Description
0	No error
1	Just exchange the sensor module but node has not been reset ==> please take out the battery for 20s then install it again to reset node to recognize the new sensor module
2	Error, sensor port M12F shorted to GND
3	Error, sensor port M12F shorted to Vcc
4	Error, sensor port M12F shorted each other
51	Check sum error of sensor port

- Lo-Byte is sensor type

Sensor type	Description
1	Ambient temperature sensor
2	Ambient humidity sensor
3	Ambient differential pressure sensor
4	Process pressure sensor
5	1-channel AC 5A current sensor
6	2-channel digital input with counters
7	2-channel digital input with status detecting
8	Ambient light sensor
9	1-channel 0-20mA analog input
10	Relay output 2 SPDT or 4 SPST
11	Soil moisture sensor with I2C
12	Soil moisture sensor with RS485
255	No sensor

5.4.3 Logic status of parameters

Hi-Byte is Logic status of parameter 1

- If parameter 1's value > high threshold 1 => Hi-Byte of Logic status = 1
- If parameter 1's value < low threshold 1 => Hi-Byte of Logic status = 0
- If parameter 1 is digital => Hi-Byte of Logic status = parameter 1's value
- Timer up 1 = (Total time when Hi-Byte of Logic status = 1)
- Timer down 1 = (Total time when Hi-Byte of Logic status = 0)
- RisingEdge counter 1 = (Counter value when Hi-Byte of Logic status changes from 0 to 1)
- FallingEdge counter 1 = (Counter value when Hi-Byte of Logic status changes from 1 to 0)

Lo-Byte is Logic status of parameter 2

- If parameter 2's value > high threshold 2 => Lo-Byte of Logic status = 1
- If parameter 2's value < low threshold 2 => Lo-Byte of Logic status = 0
- If parameter 2 is digital => Lo-Byte of Logic status = parameter 2's value
- Timer up 2 = (Total time when Lo-Byte of Logic status = 1)
- Timer down 2 = (Total time when Lo-Byte of Logic status = 0)
- RisingEdge counter 2 = (Counter value when Lo-Byte of Logic status changes from 0 to 1)
- FallingEdge counter 2 = (Counter value when Lo-Byte of Logic status changes from 1 to 0)

Packet data from 40 nodes is saved to the modbus table, use the command 04 modbus RTU to read, see the "OPERATION DATA OF 40 WIRELESS SENSORS (in the [Modbus Memmap of WS433-CL](#))"

Data status node:

Data status	
99	Have not received data from wireless sensor
0	when data from wireless sensor just arrived in within "cmp time 1" seconds. "cmp time 1" is configurable and has a default value of 15s
1	when data from wireless sensor just arrived in within "cmp time 2" seconds. "cmp time 2" is configurable and has a default value of 30s
2	when data from wireless sensor just arrived in within "cmp time 3" seconds. "cmp time 3" is configurable and has a default value of 45s
3	when data from wireless sensor just arrived in within "cmp time 4" seconds. "cmp time 4" is configurable and has a default value of 60s
4	when data from wireless sensor just arrived in within "cmp time 5" seconds. "cmp time 5" is configurable and has a default value of 300s
5	when data from wireless sensor just arrived in within "cmp time 6" seconds. "cmp time 6" is configurable and has a default value of 600s
6	when data from wireless sensor just arrived in within "cmp time 7" seconds. "cmp time 7" is configurable and has a default value of 900s
7	when data from wireless sensor just arrived in within "cmp time 8" seconds. "cmp time 8" is configurable and has a default value of 1800s
8	when data from wireless sensor just arrived in within "cmp time 9" seconds. "cmp time 9" is configurable and has a default value of 3600s
9	when data from wireless sensor had arrived longer than "cmp time 9" seconds. "cmp time 9" is configurable and has a default value of 3600s

Configure the cmp time at "SETTING TIMEOUT VALUE OF DATA STATUS (in the [Modbus Memmap of WS433-CL](#))"

- RF signal strength of node

RF signal strength	
0	RSSI < -100dBm
1	RSSI = -80...-100dBm
2	RSSI = -70...-79dBm
3	RSSI = -55...-69dBm
4	RSSI = 0...-54dBm

- Read Data status node and RF signal strength of node of 40 nodes in the area "STATUS DATA OF 40 WIRELESS SENSORS (in the [Modbus Memmap of WS433-CL](#))"

5.5 Control from WS433-CL to the node

For each node, there is a zone to control from the WS433-CL, including 8 registers (16 bytes), to see the starting address for each node at "CONTROL DATA OF 40 WIRELESS SENSORS (in the [Modbus Memmap of WS433-CL](#))".

Using the modbus 16 command to write to this area, the WS433-CL will send the RF control down to the node, then the node sends back the ACK packet, which contains data from the sending node after executing the command. control.

8 control registers for WS433-RL sensor node:

Description	#reg	Format	Explanation
Control Relay 1 of sensor Node	1	uint16	0: turn off relay 1 1: turn on relay 1
Control Relay 2 of sensor Node	1	uint16	0: turn off relay 2 1: turn on relay 2
Control Relay 3 of sensor Node	1	uint16	0: turn off relay 3 1: turn on relay 3
Control Relay 4 of sensor Node	1	uint16	0: turn off relay 4 1: turn on relay 4
spare	4		

5.6 Synchronizing configuration between WS433-CL and node:

For each node, there is a configuration synchronous zone from WS433-CL, consisting of 40 registers (80 bytes), see the start address for each node at "ADVANCED CONFIG (in the [Modbus Memmap of WS433-CL](#))".

# of register	Description	Value Range	Default	Format	Explanation
1	Cycle_wakeup	1-3600(s)	120	uint16	Every time interval of Cycle_wakeup, sensor node would ONLY send data to co-ordinator if the new measured value was changed more than the Delta value of the last measured value. Default Cycle_wakeup is 120 seconds
1	Cycle_healthsta	60-7200(s)	600	uint16	Every time interval of Cycle_healthsta, sensor node will absolutely send data to co-ordinator regardless any condition
2	Co-ordinator id		0	uint32	Configure the ID number of Co-ordinator that wireless sensor want to connect to the Co-ordinator when only adding the sensor manually

2	Radio frequency	433.05-434.79, 433 Mhz	433.92	float	Configure the operating frequency of wireless sensor by Co-ordinator, should be configured from 433.05-434.79 MHz, only for advanced users
1	Tx power	-10,10,15	15	int16	Configure the RF power of wireless sensor by Co-ordinator, only for advanced users + 15 <=> tx power = 15dBm + 10 <=> tx power = 10dBm + -10 <=> tx power = -10dBm
1	Data rate RF	0-1	0	uint16	Configure the air data rate of wireless sensor by Co-ordinator, only for advanced users + 0 <=> data rate RF at 50kbps + 1 <=> data rate RF at 625bps
2	a1		1	float	Scale value of parameter_1 = (a1 * Raw sensor value of parameter_1) + b1. For sensor value scale
2	b1		0	float	Scale value of parameter_1 = (a1 * Raw sensor value of parameter_1) + b1. For sensor value scale
2	a2		1	float	Scale value of parameter_2 = (a2 * Raw sensor value of parameter_2) + b2. For sensor value scale
2	b2		0	float	Scale value of parameter_2 = (a2 * Raw sensor value of parameter_2) + b2. For sensor value scale
2	Delta_1		0	float	Delta value, this is the threshold to allow sending data to co-ordinator when the new value of parameter 1 is changed from the last value a delta value which is higher than the threshold.
2	High_threshold_1		0	float	High threshold value for parameter 1
2	Low_threshold_1		0	float	Low threshold value for parameter 1
2	High_threshold_2		0	float	High threshold value for parameter 2
2	Low_threshold_2		0	float	Low threshold value for parameter 2
14	spare				Each type of WS node will have different configurations

When the WS433-CL power is turned on, the node's configuration will be read from flash, sync status = 99.

When the battery is plugged in or the power is turned on, the node sends the registration packet to the WS433-CL which contains the node's configuration. Configuration from the node will be overwritten on the configuration area on WS433-CL => Save flash => Sync completed, sync status = 0.

When users want to change the configuration on the node, use modbus RTU command 16 write to the configuration area on WS433-CL ==> sync status = 1: WS433-CL wait for the node to send data. When the node sends data,

WS433-CL will send configuration to node, node sends back authentication ACK containing this new configuration ==> sync status = 0: sync configuration OK, users should read this new configuration section right.

Read the Sync status of 40 nodes in the "STATUS DATA OF 40 WIRELESS SENSORS (in the [Modbus Memmap of WS433-CL](#))" area.

Sync status	
0	sync ok
1	waiting for sync
99	power-on-reset default

5.7 Configuration of RF operation parameters

- Frequency 433.05 - 434.79Mhz, default 433.92Mhz
- RF transmit power: 10 dBm, 15dBm (default)
- Data rate of RF: 50kbps (default), 625bps

=> When changing the configuration of RF parameters, it must be reset for the WS433 board to operate under the new RF configuration. However, if you use the push button or the Magnetic sensor to change the RF data rate, there is no need to reset the board

5.7.1 The procedure for changing the frequency for the sensor and Co-or is as follows:

- **Step 1:** Use the Modbus Tool to change the frequency recording of each sensor, then remove the sensor battery, wait 10 seconds and reinsert it, then wait for 30 seconds, it will receive the configuration from Co-o, then confirm that the frequency change is successful. How to check on Co-or by Modbus Tool software.
- **Step 2:** Remove that sensor battery and set it aside;
- **Step 3:** Continue to step 1 for the next sensor;
- **Step 4:** After changing the frequency for all sensors, finally change the frequency for Co-or by using the Modbus Tool to write down, then turn off the power of co-or for 10 seconds and then power again, it will run at the new frequency, and connect to the sensor at the new frequency;

5.7.2 Change data rate: See more at section "[5.3 Hall sensor and button function](#)"

5.8 Modbus communication


Configuration:

- Protocol: Modbus RTU
- Address: 1 - 247
- Baud rate: 9600 , 19200
- Parity: none, even, odd
- Stop bits: 1

6. Installation

6.1 Mounting bracket installation

The mounting bracket is made from hard metallic material. Following to these steps as the below picture



Insert the top plastic housing and locking by L hex key

(NOTE: When reinstalling the cover, pay attention to put the PCB edge into the middle slot of the box inside as shown below)



6.2 Installation location

To maximize the distance of transmission, the ideal condition is Line-of-sight (**LOS**) between the two modules. In real life, there is no LOS condition. However, the two modules still communicate each other, but the distance will be reduced significantly.


Therefore, to maximize the transmission distance, please pay attention to the following conditions:

- **DO NOT** install the wireless module inside a complete **metallic** box or housing. The signal can not pass through metallic wall;
- This wireless module would be installed a semi-metallic box, because the RF signal can pass through the non-metal wall/are;
- The best case is to install the wireless module inside or Non-metallic box;

Some non-metallic materials: plastic, glass, wood, leather, concrete, cement...


6.3 IO Wiring & Sensor installation

PIN ASSIGNMENT & WIRING




WS433-CL-H18.PNG

CONNECT WIRELESS SENSORS TO any PLC or HMI




WS433-CL-H2.PNG

CONNECT WIRELESS SENSORS TO any SCADA or IoT Platform



WS433-CL-H3.PNG

CONNECT WIRELESS SENSORS TO GLOBIOTS Platform




WS433-CL-H4.PNG

7. Troubleshooting

No.	Phenomena	Reason	Solutions
1	Cannot read modbus	<ul style="list-style-type: none"> No power supply for WS433-CL, the power cord is incorrectly connected Modbus connection pin A, B is loose or wrong Configuration slave address, baudrate, parity is not correct Reading the wrong command, wrong address register 	<ul style="list-style-type: none"> Check the power connection Check the connection modbus A, B Check the configuration of slave address, baudrate, parity WS433-CL only supports modbus 3, 4, and 16. Check if the value of modbus status returned by 2 or 3 is an incorrect address reading.

2	Failed to add auto sensor	<ul style="list-style-type: none"> When the first 5 minutes are up, the sensor cannot be added Node needs to be added further away from WS433-CL The WS433-CL and the node are configured to run at 2 different RF frequencies, or different data rates 	<ul style="list-style-type: none"> Unplug, wait 10 seconds, plug in again to enable automatic add or write to modbus Enb_auto_add_sensors = 1 Bringing nodes and WS433-CL together or temporarily setting the smaller Rssi_threshold can add sensors farther (then return the old values) Check the RF frequency, data rate of WS433-CL and the node
3	Read modbus normal health values but read the data of the node, all are 0	<ul style="list-style-type: none"> The modbus 4 command only supports FW 1.9, old FWs can't read command 4 	<ul style="list-style-type: none"> Check the FW of WS433-CL if it is older than 1.9 then use command 3 to read data and other registers
4	The node's data has no data of prm1 and prm2	<ul style="list-style-type: none"> The sensor attached to the node is loose For the WS433-M12F node, if the sensor is attached after the battery is attached to the node, the sensor type may be different so the data cannot be read. 	<ul style="list-style-type: none"> Attach the sensor to the node firmly Attach the sensor to the WS433-M12F node first. Then remove the node pin, wait for 10 seconds, re-attach to the node to re-identify the sensor

8. Support contacts

<p><u>Manufacturer</u></p>  <p>Daviteq Technologies Inc No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam. Tel: +84-28-6268.2523/4 (ext.122) Email: info@daviteq.com www.daviteq.com</p>	<p><u>Distributor in Australia and New Zealand</u></p>  <p>Templogger Pty Ltd Tel: 1800 LOGGER Email: contact@templogger.net</p>
--	---

🕒 Revision #79
★ Created Sun, Feb 23, 2020 6:29 PM by [Kiệt Anh Nguyễn](#)
✍ Updated Sat, Feb 22, 2025 3:59 AM by [Phan Van Luc](#)