

# USER GUIDE FOR ICONNECTOR 3G STHC-B-ISG02DB-03

|                            |          |
|----------------------------|----------|
| STHC-B-ISG02DB-03-MN-EN-01 | Jul-2020 |
|----------------------------|----------|

*This document is applied for the following products*

|                  |                   |  |     |                |     |
|------------------|-------------------|--|-----|----------------|-----|
| <b>SKU</b>       | STHC-B            | <b>HW Ver.</b>   | 1.1 | <b>FW Ver.</b> | 1.4 |
| <b>Item Code</b> | STHC-B-ISG02DB-03 | Iconnector 3g Dualband, internal antenna, 1 x battery size D 3.6VDC and external DC power, 1 x pulse input, 1 x 4-20mA input with 15v supply to external sensor, Ip67, 1 x M12-M for power, 1 x M12-F for IO |     |                |     |

## 1. Functions Change Log

| HW Ver. | FW Ver. | Release Date | Functions Change |
|---------|---------|--------------|------------------|
| 1.1     | 1.4     | Jun-2020     |                  |

## 2. Introduction

STHC-B is same as STHC, is a Smart IoT Gateway, aka iConnector, a main component in any IoT application. However, STHC-B is operated by a Primary battery 3.6V, suitable for applications where no grid power like Water pipeline, water network...In addition, STHC-B is also powered by external power supply 7..48VDC or Solar panel system. STHC-B has built-in 1 Pulse input to read the Pulse from flow meter...and 01 Digital input can connect to Pressure sensor, Level, Temperature, Humidity... Data will be sent back to server for data logging, data analytics, monitoring & controls...With Ultra low power design, it can uses 01 battery size D for up to 05 years (depend on configuration of data logging and sending).

### SMART IOT GATEWAY - iConnector BATTERY OPERATED STHC-B



STHC-B-H1.PNG



## 3. Specification

|                    |   |
|--------------------|---|
| Host Communication | GPRS Quadband/3G-Dual band/NB-IoT, internal antenna |
|--------------------|---|

|                                    |   |
|------------------------------------|---|
| Host communication supports        | TCP/IP, UDP/IP, FTP, HTTPS, SNMP...   |
| Vietnam Type Approval Cerification | QCVN 54:2011/BTTTT, QCVN 15:2015/BTTTT (DAVITEQ B00122019)  |
| Analog Input                       | 1 x 4-20ma input with 15v supply to external sensor   |
| Pulse Input                        | 1 x Pulse input with counting function, dry-contact, max 1Hz, auto-reset counter when reaching 9 digits |
| Digital Sensor Input               | 1 x Digital sensor input for DULP sensor type (Digital Ultra Low Power ), M12 connector, IP67           |
| Battery Supply                     | 1 x D size battery holder, 3.6VDC   |
| External Power Supply              | 7..48VDC, avg 200mA, peak 1.5A  |
| Back-up battery                    | Lithium Super Capacitor (to alert shortage of power supply)   |
| On-board logging                   | 2MB Flash   |
| SIM slot                           | 01 x micro-SIM  |
| Operating Temperature              | -20 .. + 85 degC (refer temperature working range of Battery being used)                                |
| Dimension                          | H110xW110xD70   |
| Housing                            | Poly-carbonate housing, IP67, wall mount pads   |
| Net weight                         | < 250 g (excluded Battery and Sensor)   |

## 4. Applications

### WATER LEVEL MONITORING



### SOIL MOISTURE MONITORING




## CONNECT WITH ICONNECTOR WITH 4..20mA PRESSURE SENSOR




## WIRING FOR ICONNECTOR WITH ANALOG INPUT

### CASE 1 - WORK WITH LOOP POWERED SENSOR



### CASE 2 - WORK WITH NON - LOOP POWERED SENSOR



## 5. Operation principle

### 5.1 Process of measurement

When the sensor sampling interval is reached, for example, 2 minutes (Battery Mode), iConnector will wake up and turn ON the power to supply power to the external sensor to start measuring. Depending on the type and characteristics of the external sensor, it may take a certain time to complete the measurement.

For example, the measurement time is 200mS, after this time, iConnector will read the value of the sensor by I2C, it will switch the power OFF to the external sensor to save energy.

If we supply external power through M12 connector, iConnector will run realtime.

After reading the sensor value, the raw data is **X**, it can be scaled to any technical value by the following formula:

$$Y = aX + b$$

Where

**X**: the raw value from sensor

**Y**: the calculated value for parameter 1's value or parameter 2's value

**a**: constant

**b**: constant

So, if there is no user setting for **a** and **b** ==> **Y = X**

The **Y** value will be compared with Lo and Hi threshold.

### 5.2 Configuration via Memory map

We can configure online using the memmaps shown in the table below:

| ADDRESS<br>(in decimal) | ADDRESS<br>(in hex) | LENGTH<br>(in byte) | TYPE  | NAME         | DESCRIPTION                   | UNIT | Server |
|-------------------------|---------------------|---------------------|-------|--------------|-------------------------------|------|--------|
| 8960                    | 2300                | 4                   | float | power supply | External power supply voltage | volt | R      |
| 8964                    | 2304                | 4                   | float | battery      | Battery voltage               | volt | R      |

|      |      |   |        |                        |   |     |     |
|------|------|---|--------|------------------------|---|-----|-----|
| 8982 | 2316 | 1 | byte   | gsm signal quality     | GSM signal strength   |     | R   |
| 902  | 386  | 4 | uint32 | I2C: sample_rate (sec) | sensor reading cycle, <b>e.g:</b> 60 seconds.   | sec | R/W |
| 906  | 38A  | 2 | uint16 | I2C: calc_time (ms)    | time of supplying power to the sensor before reading the I2C, <b>e.g:</b> 200 ms.   | ms  | R/W |
| 908  | 38C  | 2 | uint16 | I2C: num_of_sample     | The number of ADC samples taken in a reading of sensor data, the more samples the longer the sensor reading time. <b>For example:</b> 8 samples with each sample have a reading time of 10ms, then the total sampling time is 80ms. |     |     |
| 910  | 38E  | 4 | float  | I2C: prm1_a            | The <b>a</b> constants after calculation according to the formula   |     | R/W |
| 914  | 392  | 4 | float  | I2C: prm1_b            | The <b>b</b> constants after calculation according to the formula   |     | R/W |
| 918  | 396  | 4 | float  | I2C: prm1_hi_cut       | Cut the upper threshold of I2C<br><b>e.g: If</b> prm1_scaled_v > prm1_hi_cut <b>then</b> prm1_scaled_v = prm1_hi_cut  |     | R/W |
| 922  | 39A  | 4 | float  | I2C: prm1_lo_cut       | Cut the lower threshold of I2C<br><b>e.g: If</b> prm1_scaled_v < prm1_lo_cut <b>then</b> prm1_scaled_v = 0.   |     | R/W |
| 9398 | 24B6 | 1 | uint8  | I2C: sensor type       | Sensor type = 20 means that the I2C sensor reads 4-20mA   |     | R/W |

|      |      |   |       |                      |   |  |     |
|------|------|---|-------|----------------------|---|--|-----|
| 9399 | 24B7 | 1 | uint8 | I2C: error status    | if error status = 0, it means the sensor reading is OK, else error status = 1 is faulty.  |  | R/W |
| 9400 | 24B8 | 4 | float | I2C: prm1_scaled_val | The measured value has been scaled for the sensor<br><b>Formula to calculate scale:</b><br>$\text{prm1\_scaled\_val} = \text{prm1\_raw\_value} * \text{prm1\_a} + \text{prm1\_b}$ |  | R/W |
| 9408 | 24C0 | 4 | float | I2C: prm1_raw_valu   | Raw sensor value read from I2C  |  | R/W |

## 5.3 Offline configuration

### 5.3.1 Connection

**First, you need to prepare**



**Computer**




**UART  
Configuration Cable**

- **Step 1:** Open the cover of the iConnector




- **Step 2:** Connect the Configuration Cable to the UART Port in iConnector



- **Step 3:** Power the iConnector via M12 male connector on iConnector





- **Step 4:** Connect the USB port of the Configuration Cable to the Computer



### 5.3.2 Configuration tool


- You can download Configuration Tool with the following link:

<https://filerun.daviteq.com/wl/?id=s5QApxosVNZLbATxi0TtKVojX4ms1PxD>


- Unzip file and run file application "iconnector\_config"

| Name               | Date modified       | Type                 |
|--------------------|---------------------|----------------------|
| common_lib.dll     | 06/17/2020 9:52 AM  | Application exten... |
| iconnector_config  | 06/24/2020 11:41 AM | Application          |
| iconnector_lib.dll | 06/17/2020 9:51 AM  | Application exten... |
| mb_lib.dll         | 06/17/2020 9:52 AM  | Application exten... |

- Choose **COM Port** (the Port which is USB cable plugged in)
- Set the **BaudRate: 9600, Parity: none**



- Click "**Connect**" until the Status displays "**disconnected**" to "**connected**". It means the iConnector is being connected with computer;
- Configuration parameters:




- Write in the **Setting** column the data to be configured into iConnector
- Click **Sync** to synchronize data into iConnector
- After synchronizing the data into iConnector, if the data displayed in the **Value** column shows the corresponding data, the configuration is completed.

## 5.4 SIM configuration


iConnector 3G uses micro-SIM and needs to be configured to use the data network

1. Open iConnector cover and install the SIM card





2. Based on the information of the mobile carrier that provides the SIM card, we configure data such as **APN**, **username**, **password** on the 2G/3G tab



## 5.5 Configure sensor parameters on the iConnector

### 5.5.1 Configure **I2C\_Sensor** tab

We configure the parameters of 4-20mA sensor in **I2C Sensor** tab:

iConnector Config 2.1.5

Port: COM11 BaudRate: 9600 Parity: none

Status: **connected** tx: 369 rx: 368

10.593,tx: 54 55 41 4E 01 24 B8 00 04 12 BA  
 10.672,rx: 54 55 41 4E 81 24 B8 00 04 41 10 00 00 80 60  
 10.675,tx: 54 55 41 4E 01 24 BC 00 04 53 7B  
 10.749,rx: 54 55 41 4E 81 24 BC 00 04 00 00 00 00 D0 59  
 10.766,tx: 54 55 41 4E 01 24 C0 00 04 92 A3

Setting: Save Load

Device Info Server 2G/3G Ethernet Wifi Modbus Turn on/off Sensor Vilog I2C Sensor HTTPS Server FTP Config FTP Parameters 1-10 FTP Parameters 1

| Name                   | Value  | CLEAR | Setting | Sync                     |
|------------------------|--------|-------|---------|--------------------------|
| I2C: sample_rate (sec) | 60     |       | 60      | <input type="checkbox"/> |
| I2C: calc_time (ms)    | 200    |       |         | <input type="checkbox"/> |
| I2C: num_of_sample     | 1      |       |         | <input type="checkbox"/> |
| I2C: prm1_a            | 1      |       |         | <input type="checkbox"/> |
| I2C: prm1_b            | 0      |       |         | <input type="checkbox"/> |
| I2C: prm1_hi_cut       | 100000 |       |         | <input type="checkbox"/> |
| I2C: prm1_lo_cut       | 0      |       |         | <input type="checkbox"/> |
| I2C: prm2_a            | 1      |       |         | <input type="checkbox"/> |
| I2C: prm2_b            | 0      |       |         | <input type="checkbox"/> |
| I2C: prm2_hi_cut       | 100000 |       |         | <input type="checkbox"/> |
| I2C: prm2_lo_cut       | 0      |       |         | <input type="checkbox"/> |
| I2C: sensor type       | 20     |       |         | <input type="checkbox"/> |
| I2C: error status      | 0      |       |         | <input type="checkbox"/> |
| I2C: prm1_scaled_value | 9      |       |         | <input type="checkbox"/> |
| I2C: prm2_scaled_value | 0      |       |         | <input type="checkbox"/> |
| I2C: prm1_raw_value    | 9      |       |         | <input type="checkbox"/> |
| I2C: prm2_raw_value    | 0      |       |         | <input type="checkbox"/> |

|                        |  |
|------------------------|--|
| I2C: sample_rate (sec) | sensor reading cycle, <b>e.g:</b> 60 seconds.  |
| I2C: calc_time (ms)    | time of supplying power to the sensor before reading the I2C, <b>e.g:</b> 200 ms.  |
| I2C: num_of_sample     | The number of ADC samples taken in a reading of sensor data, the more samples the longer the sensor reading time.<br><b>For example:</b> 8 samples with each sample have a reading time of 10ms, then the total sampling time is 80ms. |
| I2C: prm1_a            | The <b>a</b> constants after calculation according to the formula  |
| I2C: prm1_b            | The <b>b</b> constants after calculation according to the formula  |
| I2C: prm1_hi_cut       | Cut the upper threshold of I2C<br><b>e.g: If</b> prm1_scaled_value > prm1_hi_cut <b>then</b> prm1_scaled_value = prm1_hi_cut   |
| I2C: prm1_lo_cut       | Cut the lower threshold of I2C<br><b>e.g: If</b> prm1_scaled_value < prm1_lo_cut <b>then</b> prm1_scaled_value = 0.  |
| I2C: sensor type       | Sensor type = 20 means that the I2C sensor reads 4-20mA  |
| I2C: error status      | if error status = 0, it means the sensor reading is OK, else error status = 1 is faulty.   |
| I2C: prm1_scaled_value | The measured value has been scaled for the sensor<br><b>Formula to calculate scale:</b> prm1_scaled_value = prm1_raw_value * prm1_a + prm1_b   |
| I2C: prm1_raw_value    | Raw sensor value read from I2C   |

## 5.5.2 Operation mode of iConnector with different power sources

When iConnector only works with D type battery:

- 3G network will turn off, only when the 3G data sending cycle is turned on to send data, after sending it will turn off.
- Not sending a ping leads to iConnector not running realtime, unable to sync from the server.
- Unable to configure from iConfig software.

When iConnector is connected to 7-48VDC power source:

- 3G network is always on, running Ping and ready to receive realtime, synchronization, running full of features.
- Can be configured from iConfig software.

## 6. Installation

### 6.1 iConnector Installation

Installed on a wall or in non-metal box.

**DO NOT** install iConnector inside a complete **metallic** box or housing. The signal can not pass through metallic wall.

iConnector should be installed in a semi-metallic box.


**Some non-metallic materials:** plastic, glass, wood, leather, concrete, cement...




### 6.2 IO Wiring & Sensor installation

## WIRING FOR ICONNECTOR WITH ANALOG INPUT


### CASE 1 - WORK WITH LOOP POWERED SENSOR



### CASE 2 - WORK WITH NON - LOOP POWERED SENSOR





Install the sensor as shown below:



- **Step 1:** Open the back cover of the sensor



- **Step 2:** Wiring to sensors



- **Step 3:** Connect Sensor to **Input 4 .. 20mA** port of iConnector via M12 connector





For more information about DP transmitter:

<https://filerun.daviteq.com/wl/?id=IT9lfZuEQUQksWLhFgSoQrs28sEGY0Kt>


## 6.3 Power Supply & Battery installation

### 6.3.1 Power Supply of iConnector

Connect 7 .. 48VDC power supply to iConnector via M12 Male connector



Use M12 female connection cable to connect to iConnector



### 6.3.2 Battery installation

#### Steps for battery installation:

- **Step 1:** Using Flat Tip Screwdrivers to open the cover



- **Step 2:** Carefully pull out the top plastic housing



|   |  |  |  |
|---|--|--|--|
| 1 | The value of the sensor is 0                   | Sensor connecting 4-20mA is loose/not connected  | Check sensor connection  |
| 2 | The iConnector does not connected to the sever | <ul style="list-style-type: none"> <li>• No power supply</li> <li>• The network information of the SIM card data is incorrect</li> <li>• No SIM card inserted</li> </ul> | <ul style="list-style-type: none"> <li>• Check the power supply</li> <li>• Check that the battery is empty or not installed correctly</li> <li>• Check the sim card configuration section</li> </ul> |
| 3 | The battery drains quickly                     | Turn On/Off tab configuration is incorrect   | Check the configuration of the Turn On/Off tab   |

🕒 Revision #24

★ Created Tue, Jun 30, 2020 11:59 PM by [Kiệt Anh Nguyễn](#)

✎ Updated Sun, Oct 31, 2021 11:22 PM by [Kiệt Anh Nguyễn](#)