


# Instructions for Grounding of Pressure Sensor


DEC-2022

## CONNECTING GND FOR SENSOR

**Step 1:** Open the blue housing of the sensor



**Step 2:** Locate the GND point on the PCB (same GND point of Battery);



**Step 3:** Solder a wire to this GND point; the other end of the wire will be screwed to 1 of 2 screws on the aluminum base;



---

🕒 Revision #3

★ Created Wed, Dec 7, 2022 12:53 AM by [Lộc Vĩnh Nguyễn](#)

✎ Updated Mon, Jan 9, 2023 2:17 AM by [Lộc Vĩnh Nguyễn](#)