HTML table for default configuration

Description	Unit	Default	Format	Property	Comment
CONSTANT_A		1	Float	R/W	Constant A for scaling measured value
CONSTANT_B		0	Float	R/W	Constant B for scaling measured value
HIGH_CUT		1000000000	Float	R/W	High cut value for calculated value
LOW_CUT		0	Float	R/W	Low cut value for calculated value
SENSOR_BOOT_TIME	ms	1000	Uint32	R/W	Boot time of sensor/input, in ms
NUM_OF_SAMPLE		10	Uint16	R/W	A number of samples for filtering function. The higher value, the more filtering

Instruction:
1, Copy from Excel. paste from row 2

2, Select all cells, configure Top alignment, background color #c6e2ff

3, Select cells in even rows, configure background color #f2f2f2 (light grey)

3, Configure all cell in first row as header type

4, Add SPACE in value of DEFAULT column for left alignment

5, Copy code and paste on wix.com, edit the width of 805px in html editor

---

Revision #2
Created Tue, Sep 5, 2023 12:53 AM by Phan Van Luc
Updated Tue, Sep 5, 2023 1:55 AM by Phan Van Luc