

USER GUIDE FOR OPTICAL DISSOLVED OXYGEN SENSOR MODBUS OUTPUT MBRTU-PODO

JUN-2021

This document is applied for the following products

1. Introduction

Optical Dissolved Oxygen Sensor with Modbus output MBRTU-PODO

- Accurate and low maintenance optical dissolved oxygen technology (luminescent quenching).
- RS485/Modbus signal output.
- Industry standard, robust body housing with 3/4" NPT on front and back.
- Flexible cable outlet: fixed cable (0001) and detachable cable (0002).
- Integrated (probe-mounted) waterproof pressure sensor.
- Automatic temperature and pressure compensation.
- Automatic salinity compensation with user-input conductivity/salinity concentration value.
- Convenient sensor cap replacement with integrated calibration.

MEASURING DISSOLVED OXYGEN IN WATER



MBRTU-PODO-H3.PNG

2. Specification

Range	DO Saturation %: 0 to 500%. DO Concentration : 0 to 50 mg/L (ppm). Operating Temperature: 0 to 50°C. Storage Temperature: -20 to 70°C. Operating Atmospheric Pressure: 40 to 115 kPa. Maximum Bearing Pressure: 1000 kPa.
Response Time	DO: T90 ~ 40s for 100 to 10%. Temperature: T90 ~ 45s for 5 - 45°C (w/ stirring).
Accuracy	DO: 0-100% < $\pm 1\%$. 100-200% < $\pm 2\%$. Temperature: $\pm 0.2\text{ }^{\circ}\text{C}$. Pressure: $\pm 0.2\text{ kPa}$.
Input /output/protocol	Input: 4.5 - 36 V DC. Consumption: average 60 mA at 5V. Output: RS485/Modbus or UART.
Calibration	1-point (100% cal point) in air-saturated water or water-saturated air (calibration bottle). 2-point: (Zero and 100% cal points).

DO Compensation Factors	<p>Temperature: automatic, full range.</p> <p>Salinity: automatic with user-input (0 to 55 ppt). Pressure: 1) compensation by instantaneous pressure value if pressure sensor is above water or less than 20cm of water.</p> <p>2) Compensation by default pressure value if the pressure sensor is more than 20cm of water. The default is obtained by the pressure sensor in the last 1-point calibration and recorded in probe memory.</p>
Resolution	<p>Low range (<1 mg/L): ~ 1 ppb (0.001 mg/L).</p> <p>Mid range (<10 mg/L): ~ 4-8 ppb (0.004-0.008 mg/L).</p> <p>High range (>10 mg/L): ~10 ppb (0.01 mg/L).* *The higher range, the lower resolution.</p>
Expected Sensor Cap Life	A useful life of up to 2 years is feasible in optimum situations.
Others	<p>Waterproof: IP68 rating with fixed cable. Certifications: RoHs, CE, C-Tick (in process). Materials: Ryton (PPS) body.</p> <p>Cable length: 6 m (options exist).</p>

3. Product Pictures

PROCESS OPTICAL DISSOLVED OXYGEN SENSOR MBRTU-PODO



MBRTU-PODO-H1.PNG

4. Wiring

Please wiring as shown below:

Wire color	Description
Red	Power (4.5 ~ 36 V DC)
Black	GND
Green	UART_RX (for upgrading or PC connection)
White	UART_TX (for upgrading or PC connection)
Yellow	RS485A
Blue	RS485B

Note: The two UART wires could be cut if not upgrading/programming probe.

5. Calibration and Measurement

DO Calibration in Options

5.1. Reset calibration

a) Reset 100% calibration.

The user write 0x0220 = 8

b) Reset 0% calibration.

The user write 0x0220 = 16

c) Reset temperature calibration.

The user write 0x0220 = 32

5.2. 1-point calibration

1-point calibration means calibrating the probe in the point of 100 % saturation, which can be obtained by one of the following means:

a) In air-saturated water (standard method).

The air-saturated water (for example of 500 mL) can be obtained by continuously (1) purging water with air using an air bubbler or some type of aeration about 3 ~ 5 minutes, or (2) stirring water by magnetic stirrer under 800 rpm for 1 hour.

After air-saturated water is ready, immerse the sensor cap and temperature sensor of the probe in the air-saturated water, and calibrate probe after the reading becomes stable (usually 1 ~ 3 minutes).

The user write 0x0220 = 1 , then waiting 30 seconds.

If the final reading of 0x0102 is not in $100 \pm 0.5\%$, please check if the stability of current testing environment or try again.

b) In water-saturated air (convenient method).

Alternatively, the 1-pt calibration can be easily done using water-saturated air, but 0 ~ 2% error might be caused depending on different operations. The recommended procedures are given as below:

i) immerse the sensor cap and temperature sensor of the probe in fresh/tap water 1~2 minutes.

ii) get out the probe and quickly dip dry the water on the surface of sensor cap by tissue.

iii) install the sensor end in the calibration/storage bottle with a wet sponge inside. Avoid direct contact of the sensor cap with any water in the calibration/storage bottle during this calibration

step. Keep the distance between the sensor cap and the wet sponge being ~ 2 cm.

v) wait for the readings to stabilize (2 ~ 4 minutes) and then write 0x0220 = 2.

5.2. 2-point calibration (100% and 0% saturation points)

(i) Put the probe in air-saturated water, write 0x0220 = 1 after the DO reading stabilizes.

(ii) After DO reading becomes 100%, move the probe to zero oxygen water (use sodium sulfide added in excess to a water sample).

(iii) Write 0x0220 = 2, after the DO reading stabilizes (~at least 2 mins).

(iv) The user reading saturation at 0x0102 for 1-point calibration, 0x0104 for 2-point calibration.

- 2-point cal is not necessary for most applications, unless users need a very accurate measurement in low DO concentration (<0.5 ppm).
- Enforcement of “0% calibration” without “100% calibration” is not allowed.

5.3. Point calibration for temperature

i) The user write 0x000A = the ambient temperature x100 (Ex: If the ambient temperature = 32.15, then the user write 0x000A=3215).

ii) The user reading temperature at 0x000A . If it is equal to what you inputted, the calibration is done. If not, please try Step 1 again.

6. Modbus RTU Protocol:

6.1. Command structure:

- Commands should not be sent sooner than 50mS from the completion of the last response.
- If the expected response from the slave is not seen for > 25mS, throw a communication error.
- Probe follows Modbus standard for functions 0x03, 0x06, 0x10, 0x17

6.2. Serial Transmission structure:

- Data types are big-endian unless otherwise noted.
- Each RS485 transmission will have: one start bit, **8 data bits, no parity bit**, and two stop bits;
- Default Baud rate: **9600** (some of the probes may have the Baudrate of 19200);
- Default Slave address: **1**
- The 8 data bits transmitted after the start bit are the most significant bit first.
- Bit Sequence

Start bit	1	2	3	4	5	6	7	8	Stop bit
-----------	---	---	---	---	---	---	---	---	----------

6.3. Timing:

- Firmware updates must be run within 5 seconds of power on or soft reset

Probe tip LED will be solid blue during this time

- First command cannot be run earlier than 8 seconds from power on or soft reset
- If there is no expected response from an issued command timeout occurs after 200ms

6.4. Modbus RTU protocol:

Register #	R/W	Details	Type	Notes
0x0003	R	LDO (mg/L) x100	UInt16	
0x0006	R	Saturation % x100	UInt16	
0x0008	R/W	Salinity (ppt) x100	UInt16	
0x0009	R	Pressure (kPa) x100	UInt16	
0x000A	R	Temperature (°C) x100	UInt16	
0x000F	R	Baud Rate	UInt16	Note 1
0x0010	R	Slave Address	UInt16	
0x0011	R	Probe ID	UInt32	
0x0013	R	Sensor Cap ID	UInt32	
0x0015	R	Probe Firmware Version x100	UInt16	Note 2
0x0016	R	Probe Firmware Minor Revision	UInt16	Note 2
0x0063	W	Baud Rate	UInt16	Note 1
0x0064	W	Slave Address	UInt16	
0x0100	R	LDO (mg/L)	Float	
0x0102	R	Saturation %	Float	
0x0108	R	Pressure (kPa)	Float	
0x010A	R	Temperature (°C)	Float	
0x010C	R/W	Current Probe Datetime	6 bytes	Note 3
0x010F	R	Error bits	UInt16	Note 4
0x0117	R	Salinity (ppt)	Float	

0x0132	R/W	Temperature Offset	Float	
0x0220	R/W	Calibration Bits	Uint16	Note 5
0x02CF	R	Membrane Cap Serial Number	Uint16	
0x0300	W	Soft restart	Uint16	Note 6

Note:

- **Note 1:** Baud rate values: 0= 300, 1= 2400, 2= 2400, 3= 4800, 4= 9600, 5= 19200, 6=38400, 7= 115200.
- **Note 2:** Firmware version is address 0x0015 divided by 100, then a decimal then address 0x0016.
Example: if 0x0015 = 908 and 0x0016 = 29, then the firmware version is v9.08.29.
- **Note 3:** Probe has no RTC, if probe is not supplied continuous power or is reset all values will reset to 0.

Datetime bytes are year, month, day, day, hour, minute, second. Most significant to least.

Example: iftheuserwrites0x010C=0x010203040506,thentheDatetime will be set to February 3rd, 2001 4:05:06 am.

- **Note 4:** Bits are counted least significant to most, starting at 1:
 - o Bit 1 = Measurement Calibration Error.
 - o Bit 3 = Probe Temperature out of range, maximum 120 °C.
 - o Bit 4 = Concentration out of range: minimum 0 mg/L, maximum 50 mg/L.
 - o Bit 5 = Probe Pressure Sensor Error.
 - o Bit 6 = Pressure Sensor out of range: minimum 10 kPa, maximum 500 kPa.
 Probe will use default pressure = 101.3 kPa.
 - o Bit 7 = Pressure Sensor Communication error, Probe will use default pressure = 101.3 kPa.

- **Note 5:**

Write (0x0220)	1	Run 100% calibration.
	2	Run 0% calibration.
	8	Reset 100% calibration.
	16	Reset 0% calibration.
	32	Reset temperature calibration.

- **Note 6:** If 1 is written to this address a soft restart is performed, all other read/writes are ignored.
- **Note 7:** if the probe has a built in pressure sensor this is a read only address.
- **Note 8:** These Values are results of 2 point calibration, while the address of 0x0003 and 0x0006 present the results of 1 point calibration.

6.5. Example Transmissions

CMD: Read Probe Data

Raw Hex: 01 03 0003 0018 B5C0

Address	Command	Start Address	# of Registers	CRC
0x01	0x03	0x0003	0x0018	0xB5C0
1	Read	3	0x18	

Example 1 response from probe:

Raw Hex: 01 03 30 031B 0206 0000 2726 0208 0BB8 27AA 0AAA 0000 0000 0000 0BB8 0005 0001 0001 0410 0457 0000 038C 0052 0001 031D 2741 0000 FAD4

Concentration (mg/L)	Saturation %	Salinity (ppt)	Pressure (kPa)	Temperature (°C)	Concentration 2pt (mg/L)	Saturation % 2pt
0x031B	0x2726	0x0BB8	0x27AA	0x0AAA	0x031D	0x2741
7.95 mg/L	100.22%	30 ppt	101.54 kPa	27.30 °C	7.97 mg/L	100.49%

Example 2 response from probe:

Raw Hex: 01 03 30 0313 0206 0000 26F3 0208 0000 27AC 0AC8 0000 0000 0000 0000 0005 0001 0001 0410 0457 0000 038C 0052 0001 031A 2748 0000 5BC0

Concentration (mg/L)	Saturation %	Salinity (ppt)	Pressure (kPa)	Temperature (°C)	Concentration 2pt (mg/L)	Saturation % 2pt
0x0313	0x26F3	0x0000	0x27AC	0x0AC8	0x031A	0x2748
7.87 mg/L	99.71%	0 ppt	101.56 kPa	27.60 °C	7.94 mg/L	100.56 %

CMD: Run 100 % Calibration

Raw Hex: 01 10 0220 0001 02 0001 4330

Address	Command	Start Address	# of Registers	# of Bytes	Value	CRC
0x01	0x10	0x0220	0x0001	0x02	0x0001	0x4330
1	Write Multi	544	1	2	Run 100% Cal	

Example 1 response from probe:

Raw Hex: 01 10 0220 0001 01BB Success!

CMD: Run 0 % Calibration

Raw Hex: 01 10 0220 0001 02 0002 0331

Address	Command	Start Address	# of Registers	# of Bytes	Value	CRC
0x01	0x10	0x0220	0x0001	0x02	0x0002	0x0331
1	Write Multi	544	1	2	Run 0% Cal	

Example 1 response from probe:

Raw Hex: 01 10 0220 0001 01BB Success!

CMD: Update Salinity = 45.00 ppt, Pressure =101.00 kPa, and Temperature = 27.00 °C

Raw Hex: 01 10 0008 0003 06 1194 2774 0A8C 185D

Address	Command	Start Address	# of Registers	# of Bytes	Value	CRC
0x01	0x10	0x0008	0x0003	0x06	0x1194 2774 0A8C	0x185D
1	Write Multi	719	1	2	45, 101, 27	

Example 1 response from probe:

Raw Hex: 01 10 0008 0003 01CA Success!

CMD: Update Cap Number with 1111

Raw Hex: 01 10 02CF 0001 02 0457 D751


Address	Command	Start Address	# of Registers	# of Bytes	Value	CRC
0x01	0x10	0x02CF	0x0001	0x02	0x0457	0xD751
1	Write Multi	719	1	2	1111	

Example 1 response from probe:

Raw Hex: 01 10 02CF 0001 304E Success!

7. Dimensions

DIMENSION DRAWING OF MBRTU-PODO (Unit: mm)



MBRTU-PODO-H2.PNG

8. Maintenance

8.1. Probe maintenance includes cleaning the sensor cap, as well as the proper conditioning, preparation, and storage of the test system.

8.2. When the probe is not in use, it is highly recommended to store the probe with its sensor cap installed and the calibration/storage bottle which was included in the original packaging, threaded onto the probe. A beaker of clean water or a moist/humid capping mechanism can also suffice if the calibration/storage bottle is not available. The sponge inside the calibration/storage bottle should be kept moist for best results.

8.3. Avoid sensor cap touching organic solvent, scratching, and abusive collisions to strengthen and lengthen the working life of the sensor cap. Special care should be taken to clean the coating of cap, to dip probe and cap in fresh water, and then to tap dry the surface with a tissue. Do not wipe the coating surface.

8.4. Replace the sensor cap, if the cap coating is faded or stripped away. DO NOT touch the clear window on the probe tip after unscrewing the old cap. If any contaminants or residue are present on the window or inside the cap, carefully remove them with a powder free wipe. Then re-screw the new sensor cap onto the probe.

9. Contact



No.11 Street 2G, Nam Hung Vuong Res., An Lac Ward, Binh Tan Dist., Ho Chi Minh City, Vietnam.
Tel: +84-28-6268.2523/4 (ext.122)
Email: info@daviteq.com | www.daviteq.com

-
- 🕒 Revision #33
 - ★ Created Wed, Jun 16, 2021 11:27 PM by [Vũ Hoàng Anh Tài](#)
 - ✎ Updated Tue, Jan 18, 2022 1:50 AM by [Lộc Vĩnh Nguyễn](#)